



DCBF-125

DCCF-150

CONDENSING GAS FIRED BOILER



Manufactured by:
ECR International Inc.
2201 Dwyer Avenue, Utica, NY 13501
Tel. 800 253 7900
www.ecrinternational.com

DCCF-150



CONTENTS :

*INSTALLATION, OPERATION,
AND MAINTENANCE MANUAL*
(240012564)

APPLICATION GUIDE
(240012560)

COMMISSIONING
GUIDE
(240011376)

REQUIRED
INSPECTION SPECIAL
(240011561)
BACK COVER

DCBF-125






CONDENSING GAS FIRED

INSTALLATION, OPERATION & MAINTENANCE MANUAL

Models

DCBF-125, DCCF-150



Manufactured by:
ECR International Inc.
2201 Dwyer Avenue, Utica, NY 13501
Tel. 800 253 7900
www.ecrinternational.com
PN 240012564 REV. A [05/15/2019]

VERIFY CONTENTS RECEIVED

| | | | |
|---|---|--|---|
|  |  |  |  |
| <p>Fully Assembled Boiler</p> | <p>30 PSI Safety Relief Valve</p> | <p>Temperature Pressure Gauge (2" Shank)</p> | <p>G3/4 NPT Ball Gas Shutoff Valve</p> |
|  | <p>4ea - 17x24x2" Gaskets 4ea - 1/2" AFM Gaskets</p> | <p>Includes Essential Documents and Warranty 11x17 Wire Diagrams</p> | |
| <p>DHW Optional Pipe Heat Only Boiler</p> | <p>Used for Valve Connections</p> | <p>Document Package</p> | |

TABLE OF CONTENTS

| | | | |
|--|-----------|--|-----------|
| Verify contents received..... | 2 | 9.12 Chimney Sweep Function (CO2 Adjust) | 41 |
| Table of contents..... | 3 | 9.13 Combustion Adjustment Function (CO2%) | 41 |
| Physical Data..... | 4 | 9.14 Check Firing Rate | 41 |
| 1 - Important Information..... | 6 | 9.15 Description Of Parameters: Factory Settings | 42 |
| 2 - Introduction..... | 7 | 9.16 Adjusting Maximum Heating Power | 44 |
| 3 - Component Listing | 8 | 10 - Operating instructions | 45 |
| 4 - Locating Boiler | 10 | 10.1 Testing For Gas Leaks And Purging The Gas Supply | 45 |
| 5 - Combustion Air And Vent Piping..... | 12 | 10.2 Boiler Operation | 45 |
| 5.1 General..... | 12 | 10.3 Central Heating Mode..... | 45 |
| 5.2 Removal of Existing Boiler From Common Vent System | 12 | 10.4 Domestic Hot Water Mode | 45 |
| | 12 | 10.5 Frost Protection..... | 45 |
| 5.3 Definitions..... | 13 | 10.6 Pump..... | 45 |
| 5.4 Approved Venting Materials | 14 | 10.7 Low Water Pressure Sensor (Internal) | 45 |
| 5.5 Vent Termination..... | 14 | 11 - General Maintenance and Cleaning..... | 46 |
| 5.6 Coaxial Venting Instructions | 15 | 11.1 Beginning of Each Heating Season | 46 |
| 5.7 Coaxial Vent Screw Placement | 15 | 11.2 Maintenance And Routine Servicing..... | 47 |
| 5.8 Twin Pipe Systems..... | 17 | 11.3 Component Replacement And Cleaning | 47 |
| 5.9 Securing Twin Pipe Polypropylene Venting | 18 | 11.4 Draining the Boiler..... | 48 |
| 5.10 (3" /80 mm Only) Flexible Vent System | 21 | 11.5 Draining the Heating Circuit | 48 |
| 5.11 Condensate Piping..... | 23 | 11.6 Hydraulic Unit (DHW)..... | 49 |
| 6 - Hydronic Piping..... | 24 | 11.7 Cleaning The Cold Water Filter | 49 |
| 6.1 General..... | 24 | 11.8 Final Commissioning | 49 |
| 6.2 Special Conditions | 24 | 11.9 Final Assembly | 49 |
| 6.3 Safety Relief Valve and Air Vent | 25 | 11.10 User Information | 50 |
| 6.4 Trim Piping | 25 | 11.11 Safety Flue Thermostat - DO NOT disable this safety device. | 50 |
| 6.5 System Piping..... | 25 | 11.12 Flue Pressure Switch- DO NOT disable this safety device. | 50 |
| 6.6 External Optional Low Water Cut Off | 27 | 11.13 Replacement Parts | 50 |
| 6.7 Central Heating System | 29 | 12 - Ratings And Capacities..... | 51 |
| 6.8 Domestic Hot Water Mode | 29 | 12.1 Ratings and Capacity | 51 |
| 6.9 Frost Protection Mode | 29 | 12.2 Domestic Hot Water Specifications..... | 51 |
| 6.10 Pump Protection..... | 29 | 12.3 High Altitude Ratings and Capacity | 51 |
| 7 - Gas Supply Piping | 30 | 12.4 High Altitude Chart | 51 |
| 7.1 General..... | 30 | 13 - Trouble Shooting..... | 52 |
| 7.2 Leak Check Gas Piping..... | 31 | 13.1 Error Messages And Resetting The Boiler | 52 |
| 7.3 Gas Orifice | 31 | 13.2 Anomalies Table for the Installer - Use this table to report the anomaly values. | 54 |
| 8 - Electrical Connections | 32 | 14 - Glossary | 55 |
| 8.1 General..... | 32 | Appendix A - Wiring Diagrams..... | 57 |
| 8.2 Install Room Thermostat | 32 | Appendix A - Wiring Diagrams..... | 58 |
| 8.3 Electrical Connections | 32 | | |
| 8.4 Access To Connection Block | 33 | | |
| 8.5 Main Supply Connection | 33 | | |
| 8.6 Install Room Thermostat | 34 | | |
| 8.7 Optional Electrical Connections..... | 34 | | |
| 8.8 Indirect Storage Tank..... | 35 | | |
| 9 - Start Up Procedure..... | 36 | | |
| 9.1 Central Heating System Connections - Heat Only..... | 36 | | |
| 9.2 Central Heating System Connections - Combi..... | 36 | | |
| 9.3 System Start Up..... | 37 | | |
| 9.4 Fill Condensate Trap with Water | 37 | | |
| 9.5 Control Panel | 38 | | |
| 9.6 Prior to Commissioning | 39 | | |
| 9.7 Commissioning For The First Time: | 39 | | |
| 9.8 Automatic Calibration Function..... | 39 | | |
| 9.9 Manual Calibration Function: | 40 | | |
| 9.10 De-Aeration Function | 40 | | |
| 9.11 Commission Set Up (Gas) - Changing The Type Of | 40 | | |
| Gas..... | 40 | | |

PHYSICAL DATA

Dimensions

| DIMENSIONS | 125 & 150 | |
|---|-----------------------------------|-----------------------------------|
| Height (Bottom of boiler top of safety Valve) | 43.65" [1.09 m] | |
| Overall Width with Manifold | 24.70" [628 mm] | |
| Depth | 17.46" [444 mm] | |
| Condensate Trap Connection | 3/4" NPT | |
| System Supply | 1 1/4" Sweat Connection | |
| DHW Outlet (125 Optional) | (125) 3/4" Sweat Connection | (150) 1/2" Sweat Connection |
| Gas Connection | 3/4" NPT | |
| DHW (Cold Water) Inlet | (125) NA | (150) 1/2" Sweat Connection |
| System Return | 1 1/4" Sweat Connection | |
| Boiler Filling Connection | External to Boiler | |
| Primary Water Content | 1 gal [3.60 L] | |

SYSTEM


| Central Heating (Sealed System) | 125 / 150 |
|---|--|
| Heat Exchanger Max Allowable Working Pressure | 50 psi [3.45 bar] |
| Max System Pressure | 30.00 psi [2.11 bar] |
| Min System Pressure | 7.25 psi [0.50 bar] |
| Max System temperature | 176°F [80°C] |
| Pressure Relief Valve Setting | 30.00 psi [2.11 bar] |
| Expansion Tank Minimum Size (pre-charge press.) | 2.2 gal at 11.6 psi [10.0 L at 0.8 bar] |
| Recommended System Pressure (cold) | 21.7 psi [1.5 bar] |

| Domestic Hot Water (Sealed System) | 150 |
|------------------------------------|-----------------------|
| Max Inlet Water Pressure | 116 psi [8 bar] |
| Min Inlet Water Pressure | 2.9 psi [0.2 bar] |
| Min DHW Flow Rate | 0.55 gpm [2.50 L/min] |
| Max DHW Temperature | 140°F [60°C] |
| DHW Water Content | 0.05 gal [0.23 L] |


When boiler is operating at maximum operating temperature, providing heating with all heat emitters operating, pressure gauge should not indicate more than 26.11 psi / 1.80 bar. If reading exceeds this figure larger expansion tank is required.

PHYSICAL DATA


Top View All Models




Left Side View All Models



Front View All Models



Right Side View All Models



1. Safety Information

Boiler installation shall be completed by qualified agency. See glossary for additional information.

⚠ WARNING

Fire, explosion, asphyxiation and electrical shock hazard. Improper installation could result in death or serious injury. Read this manual and understand all requirements before beginning installation.


⚠ WARNING

Do not tamper with or use this boiler for any purpose other than its intended use. Failure to follow these instructions could result in death or serious injury. Use only manufacturer recommended parts and accessories.

⚠ CAUTION

Laceration, burn hazard. Metal edges and parts may have sharp edges and/or may be hot. Use appropriate personal protection equipment to include safety glasses and gloves when installing or servicing this boiler. Failure to follow these instructions could result in minor or moderate injury.

Become familiar with symbols identifying potential hazards.

 This is the safety alert symbol. Symbol alerts you to potential personal injury hazards. Obey all safety messages following this symbol to avoid possible injury or death.

⚠ DANGER

Indicates a hazardous situation which, if not avoided, WILL result in death or serious injury.

⚠ WARNING

Indicates a hazardous situation which, if not avoided, could result in death or serious injury.

⚠ CAUTION

Indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.

NOTICE

Used to address practices not related to personal injury.

FOR YOUR SAFETY READ BEFORE OPERATING

⚠ DANGER



Hot Water Can Scald!

Water heated to temperature for clothes washing, dish washing and other sanitizing needs can scald and cause permanent injury.

Children, elderly, and infirm or physically handicapped persons are more likely to be permanently injured by hot water. Never leave them unattended in bathtub or shower. Never allow small children to use a hot water tap or draw their own bath.

If anyone using hot water in the building fits the above description, or if state laws or local codes require certain water temperatures at hot water taps, you must take special precautions:

- Use lowest possible temperature setting.
- Install some type of tempering device, such as an automatic mixing valve, at hot water tap or water heater. Automatic mixing valve must be selected and installed according to manufacturer's recommendations and instructions.
- Water passing out of drain valves may be extremely hot. To avoid injury:
 - Make sure all connections are tight.
 - Direct water flow away from any person.

| Water Temperature Setting | 1st Degree Burn Exposure Time For An Adult | 2nd and 3rd Degree Burn Exposure Time For An Adult |
|---------------------------|--|--|
| 120° F | 1 minute | 5 minutes |
| 130° F | 5 seconds | 30 seconds |
| 140° F | 2 seconds | 5 seconds |
| 150° F | 1 second | 1.5 seconds |
| 160° F | Instantaneous | 0.5 seconds |

Note: Warning for Infants, Children, and Elderly: Great care must be taken when exposing the aforementioned groups to warm or hot water as they can be badly burned in exposure times less than half of the time for an adult.

2 - Introduction

2.1 Installation shall conform to requirements of authority having jurisdiction or in absence of such requirements:

UNITED STATES

- National Fuel Gas Code, ANSI Z223.1/NFPA 54.
- National Electrical Code, NFPA 70.

2.2 Where required by authority having jurisdiction, installation shall conform to Standard for Controls and Safety Devices for Automatically Fired Boilers, ANSI/ASME CSD-1.

Additional manual reset low water cutoff may be required.

2.3 Requirements for Commonwealth of Massachusetts:

Boiler installation must conform to Commonwealth of Massachusetts code 248 CMR which includes but is not limited to:

Installation by licensed plumber or gas fitter.

2.4 Manufacturer recommends use of Carbon Monoxide monitor may be requirement of local jurisdiction.

2.5 Designated Use

- DCCF-150 provide both central heating and domestic hot water.
- DCBF-125 central heating only.
- Indoor installation.
- Closet or alcove installation. Direct Vent Boiler does not require air vents when installed in closet or room.
- Direct vent boiler.
- For use with natural gas or liquefied petroleum gases (LP/propane).

2.6 The unit **MUST NOT**:

- Directly heat potable water. Indirect heating is acceptable.
- Heat water with non-hydronic heating system chemicals present (example, swimming pool water).
- Toxic chemicals, such as those used for boiler treatment, shall not be introduced into potable water used for space heating.
- Exceed 43 psig (2.96 bar) maximum system pressure, or drop below minimum system pressure 7.25 psig (.50 bar)
- Exceed 176°F (80°C) system design temperature.


2.7 Operational Features

- Modulates to provide CH Turndown 5.5:1, DHW Turndown 7:1.
- Maximum output available for domestic hot water:
DCCF-150 - 136,000 btu/h (40 kW), capable of providing 3.5 (U.S.) gpm (13.2 liters/min) with a temperature rise of 70°F/39°C.
- Integral Low Water Pressure Cutoff.
- Optional Outdoor Temperature Reset.
- Heat exchanger over heat protection.
- Boiler operating at maximum operating temperature, providing heat, pressure gauge should not indicate more than 26.11 psi / 1.80 bar. If reading exceeds this figure larger expansion tank is required.

Check our website frequently for updates: www.ecrinternational.com

Information and specifications outlined in this manual in effect at the time of printing of this manual. ECR International reserves the right to discontinue, change specifications or system design at any time without notice and without incurring any obligation, whatsoever.


DUNKIRK - DCBF 125



| ITEM NO. | Dunkirk DCBF-125 |
|----------|---|
| 1 | Coaxial Connector |
| 2 | Flue Sensor |
| 3 | Heat Exchanger |
| 4 | Burner (not shown) |
| 5 | Flame Detection Electrode |
| 6 | Air/Gas Blend Manifold |
| 7 | Venturi |
| 8 | Fan |
| 9 | Pump with Air Separator |
| 10 | Boiler Drain Tap |
| 11 | Heating Return |
| 12 | Gas Inlet |
| 13 | Optional Indirect Tank Connection |
| 14 | Heating Supply Connection |
| 15 | Condensate Connection |
| 16 | Low Water Pressure Cutoff |
| 17 | 3-Way Valve with Motor |
| 18 | Gas Valve |
| 19 | Water Safety Thermostat |
| 20 | NTC Heating sensor (Flow/Return) QTY 2, (1 Shown for clarity) |
| 21 | Ignition Electrode |
| 22 | Pressure Switch |
| 23 | Pressure Relief Valve |

Illustrations are a depiction of the boiler for general location of parts and may vary depending on model.

DUNKIRK DCCF-150



| ITEM NO. | Dunkirk DCCF-150 |
|----------|---|
| 1 | Coaxial Connector |
| 2 | Flue Sensor |
| 3 | Heat Exchanger |
| 4 | Burner (not shown) |
| 5 | Flame Detection Electrode |
| 6 | Air/Gas Blend Manifold |
| 7 | Venturi |
| 8 | Fan |
| 9 | Pump with Air Separator |
| 10 | DHW Priority Sensor |
| 11 | Flow Sensor with Water Filter and Flow Restrictor |
| 12 | Boiler Drain Tap |
| 13 | Heating Return |
| 14 | Cold Water DHW Inlet Tap |
| 15 | Gas Inlet |
| 16 | DHW Outlet |
| 17 | Heating Supply Connection |
| 18 | Condensate Connection |
| 19 | DHW Heat Exchanger |
| 20 | NTC DHW Sensor |
| 21 | Low Water Pressure Cutoff |
| 22 | 3-Way Valve with Motor |
| 23 | Gas Valve |
| 24 | Water Safety Thermostat |
| 25 | NTC Heating sensor (Flow/Return) QTY 2, (1 Shown for clarity) |
| 26 | Ignition Electrode |
| 27 | Pressure Switch |
| 28 | Pressure Relief Valve |

Illustrations are a depiction of the boiler for general location of parts and may vary depending on model.

⚠ WARNING

Fire Hazard! Do not install on carpeting. Failure to follow these instructions could result in death or serious injury.

4.1 Boiler Location Considerations

- Ambient room temperature always above 32°F (0°C) to prevent freezing of liquid condensate.
- Approved for installation in closets or alcove provided it is correctly designed for that purpose and minimum clearances are met.
- Protect gas ignition system components from water (dripping, spraying, rain, etc.) during operation and service (circulator replacement, condensate trap, control replacement, etc.).
- Access to outdoors to meet minimum and maximum pipe lengths for combustion air and vent piping. See section 6.
- Disposal of condensate. See section 6.
- Drainage of water (or water - antifreeze solution) during boiler service or from safety relief valve discharge. See section 5.
- Access to system water piping, gas supply, and electrical service. See sections 5, 7 and 8.
- Clearances to combustible materials and service clearances. See Table 1 and Figures pg. 11.
- Room-sealed boiler installed in a room containing bath or shower shall be installed so person using bath or shower cannot touch any electrical switch or boiler control utilizing line voltage electricity.
- Multiple Boilers can be placed side by side, or back to back.
- Observe service clearances in all installations.
- For Direct Vent installations, air vents are not required in room boiler is installed in, or when installed in closet or compartment.

⚠ WARNING

Fire, explosion, and asphyxiation hazard. Improper installation could result in death or serious injury. Read these instructions and understand all requirements before beginning installation.

⚠ WARNING

Fire hazard. Do not install boiler on combustible flooring or carpeting. Failure to follow these instructions could result in death or serious injury.

4.2 Floor Location

- Place crated boiler as close to selected location as possible and un-crate boiler. Boiler may be moved into position with appliance dolly or 2 wheel hand truck. Insert dolly or hand truck under left hand side of boiler. It is possible to slide boiler for short distance on smooth floor or surface.
- Adjust the position of the boiler verify it is level and plumb.
- Select level location central to piping systems served and as close to vent and air intake terminals as possible.
- Accessibility clearances, if more stringent (i.e. larger clearances) than required fire protection clearances, must be used for boiler installation. Accessibility clearances may be achieved with the use of removable walls or partitions.
- Boiler is approved for installation in closets and on combustible floors. ***This boiler shall NOT be installed on carpeting.***
- Install equipment in location which facilitates operation of venting and combustion air intake piping systems as described in this manual.
- Advise owner to keep venting and combustion air intake passages free of obstructions. Both venting and combustion air intake piping systems connected to outdoors must permit flow through piping systems without restrictions for boiler operation.
- Keep boiler area clean of debris and free of flammable and combustible materials, vapors and liquids.

4 - LOCATING BOILER


4.3 Clearances

| TABLE 1: BOILER CLEARANCES | | |
|-----------------------------------|--------------------------------------|--|
| Dimension | Combustible Materials ⁽¹⁾ | Manufacturer Recommended for Service ⁽¹⁾⁽²⁾ |
| Top | 0" (0 cm) | 8-5/8" (220 mm) |
| Left Side | 1-3/4" (45 mm) | 12" (305 mm) |
| Right Side | 1-3/4" (45 mm) | 1-3/4" (45 mm) |
| Front | 0" (0 mm) | 17-3/4" (450 mm) |
| Back | 0" (0 mm) | 0" (0 mm) |
| Bottom | 0" (0 mm) | 0" (0 mm) |
| Combustion Air/Vent piping | 0" (0 mm) | 6" (160 mm) |


⁽¹⁾ Required distances measured from boiler jacket.
⁽²⁾ Service, proper operation clearance recommendation.
 * Allowance for piping and venting not included.

NOTE: Greater clearances for access should supersede fire protection clearances.

Service Clearances



Combustible Clearances



0 in /0 mm between Back of Unit and wall

⚠ WARNING

Fire, explosion, and asphyxiation hazard. Improper installation could result in death or serious injury. Read these instructions and understand all requirements before beginning installation.

⚠ WARNING

ABS/PVC venting shall not be used this product. Use of DWV plumbing pipes to vent this boiler shall be prohibited. Use of cellular core PVC (ASTM F891), cellular core CPVC, or Radel® (polyphenolsulfone) in venting systems shall be prohibited. Covering non-metallic vent pipe and fittings with thermal insulation shall be prohibited. Failure to follow these instructions could result in death or serious injury.

NOTICE

Follow venting manufacturer's equivalent lengths for specialty fittings.

5.1 General

- Installations shall comply with Authority having jurisdiction and in absence of such with:
 - » U.S. ANSI Z223.1 /NFPA 54 in the United States
- This boiler requires a dedicated direct vent system.
- Vent connections serving appliances vented by natural draft shall not be connected into any portion of mechanical draft systems operating under positive pressure.
- Use only manufacturer approved venting materials or venting materials primer and glue approved to: ULC S636 in Canada, or UL 1738 in the U.S.
- Materials used in the U.S. shall comply with Authority having jurisdiction and in absence of such with: ANSI/ASTM D1785, ANSI/ASTM F441, ANSI/ASTM F493.
- Vent system must have unrestricted movement through walls, ceilings and roof penetrations.
- Check for proper joint construction when joining pipe to fittings.
- If vent is penetrating ceilings and floors, openings must have means of fire stopping in joist areas and proper fire-stop spacer assemblies installed.
- Standard roof flashing methods must be used to install roof flashing.
- Frame wall and roof openings to provide support for attachment of termination assemblies.
- Support piping in accordance with pipe manufacturer's instruction and authority having jurisdiction. In absence of manufacturer's instruction use pipe hooks, pipe straps, brackets, or hangers of adequate and strength located at intervals of 3 ft (1 m) or less. Allow for expansion/contraction of pipe.
- Venting shall be supported adjacent to each joint using steel strapping or equivalent. See Figure 5-1.

- Support horizontal sections of vent pipe to prevent sags capable of accumulating condensate.
- Assemble vent materials in accordance with venting manufacturer's instructions.
- Slope exhaust pipe minimum of 1/4" per foot, or vent manufacturer's recommendation, whichever is greater; back toward the boiler.
- Any "in line" elbows in flue system must be taken into consideration. First elbow on the top of the boiler is included in equivalent length calculations.
- Use U.V. stabilized polypropylene when it will be exposed to sunlight, wind, or prone to freeze ups.
- Manufacturer requires use of an approved mechanical fastener, which may vary per vent pipe manufacturer, at every push-fit gasket connection when using a single wall polypropylene vent system.


5.2 Removal of Existing Boiler From Common Vent System

When existing boiler is removed from common venting system, common venting system is likely to be too large for proper venting of appliances remaining connected to it.

After removal of existing boiler, following steps shall be followed with each appliance remaining connected to common venting system placed in operation, while other appliances remaining connected to common venting system are not in operation:


- Seal any unused openings in common venting system.
- Visually inspect venting system for proper size and horizontal pitch. Determine there is no blockage or restrictions, leakage, corrosion and other deficiencies which could cause an unsafe condition.
- When practical, close all building doors, windows, and all doors between space in which appliances remaining connected to common venting system are located and other spaces of building. Turn on clothes dryer and any appliance not connected to common venting system. Turn on exhaust fans, such as range hoods and bathroom exhaust so they will operate at maximum speed. Do not operate summer exhaust fan. Close fireplace dampers.
- Turn on appliance being inspected. Follow lighting instructions. Adjust thermostat so appliances will operate continuously.
- Test for spillage at draft hood relief opening after 5 minutes of main burner operation. Use flame of match or candle, smoke from cigarette, cigar or pipe.
- Determine each appliance remaining connected to common venting system properly vents when tested as outlined above. Then return doors, windows, exhaust fans and any other gas-burning appliance to their previous condition of use.
- Any improper operation of common venting system should be corrected so installation conforms with National Fuel Code, ANSI Z223.1/NFPA 54 and/or Natural Gas and Propane Installation Code, CAN/CSA B149.1. When re-sizing any portion of common venting system, common venting system should be re-sized to approach minimum size as determined using appropriate tables in Chapter 13 of the National Fuel Gas Code, ANSI Z223.1/NFPA 54 and/or Natural Gas and Propane Installation Code, CAN/CSA B149.1.

Figure 5-1 - Venting Support




5.3 Definitions

1. **Coaxial piping** – Exhaust and air intake pipe have a common axis.
2. **Twin Pipe** – Exhaust and intake air are separate pipes,



can be terminated using single wall terminals from the vent manufacturer or field built configuration using elbows or tees.



5 - COMBUSTION AIR AND VENT PIPING

5.4 Approved Venting Materials

⚠ WARNING

Manufacturer recommends this condensing boiler be vented with approved polypropylene venting material. Use only materials listed below for vent pipe, intake air pipe, and fittings. Failure to comply could result in death or serious injury.

⚠ WARNING

- Covering non-metallic vent pipe and fittings with thermal insulation shall be prohibited.
- Use of cellular core PVC for venting flue gas could result in death, or serious injury.
- Coaxial venting shall be fastened with screws. Dual flue venting is NOT fastened with screws.

⚠ WARNING

Do not use cellular core pipe. Only specified sized pipes are to be used. When using venting material other than boiler manufacturer's venting, note the correct installation procedure. Failure to follow these instructions could result in death, or serious injury.

Installation shall conform to requirements of authority having jurisdiction or in absence of such requirements:

- USA - National Fuel Gas Code, ANSI Z223.1/NFPA 54.
1. Venting shall be properly supported.
 2. Boiler shall not support any type of vent system.

3. All piping, glue, solvents, cleaners, fittings and components must conform to ASTM and ANSI standards. In Canada ULC S636 and in the USA UL 1738 schedule 40 CPVC are the only approved vent system to be used as an alternative to polypropylene venting for the exhaust pipe.
4. Manufacturer requires use of a mechanical fastener at every push-fit gasket connection when using a single wall polypropylene vent system.

Approved Polypropylene Manufacturers

* Natalini

5.5 Vent Termination

- Terminate combustion air and vent pipes with fittings or coaxial vent kit.

Use horizontal pipe for vent and 90° elbow for combustion air termination when using fittings.

- Separate vent terminal from air inlet terminal to prevent flue gas recirculation. If T-Terminal is used on flue pipe at sidewall, air inlet terminal shall be at least 36" or more away from vent terminal.
- Locate combustion air termination as far as possible from swimming pool, swimming pool pump house, and other sources of airborne chlorine.
- Locate combustion air and vent terminals as required by authority having jurisdiction.

* DuraVent®

* Centrotherm

* Z-Flex®

Note: Maximum equivalent length may vary between manufacturers.

| Vent Material Options | |
|--|--|
| 125 & 150 | |
| 1 | 4" / 2" [100 mm / 50 mm] polypropylene coaxial. |
| 2 | 3" [80 mm] polypropylene twin pipe. Shall be polypropylene on BOTH intake and exhaust. |
| 3 | 2" [50 mm] polypropylene twin pipe. Shall be polypropylene on BOTH intake and exhaust. |
| 4 | 3" [80 mm] flexible polypropylene for chimney exhaust vent, shall have rigid 3" [80 mm] polypropylene on air intake. |
| 5 | 3" [80 mm] Twin pipe CPVC. PVC optional on intake ONLY. |
| * Note: Adapters and fittings used with all vent systems shall be from same manufacturer and compatible with the vent pipe. See list for approved Manufacturers. | |

5.6 Coaxial Venting Instructions

Maximum equivalent flue lengths for Coaxial venting are:


| Coaxial Pipe Vent Lengths (Includes first elbow and termination) | | |
|---|-------------------------|----------------|
| Boiler Size | 125/150 | |
| Vent Size | 4"/2" [100 mm/50 mm] | |
| | Maximum | Minimum |
| Natalini | 32.80 ft [10 m] | 6 ft [1.8m] |
| DuraVent® | 27.88 ft [8.5 m] | |
| Centrotherm | 24.60 ft [7.5 m] | |

| Coaxial Elbows - Equivalent length | |
|--|------------------|
| 4"/2" [100 mm/60 mm] | |
| 45° | 1.64 ft. [0.5 m] |
| 90° | 3.28 ft. [1.0 m] |
| Coaxial Termination - Equivalent length 3 ft (0.9 m) | |

NOTE: Coaxial venting can run horizontal or vertical.

- Connect flue elbow to top of boiler and adjust direction of elbow to desired orientation (rear, right or left).
- Measure distance from outside wall face to elbow, this dimension will be known as 'X', add distance "Y" + 2" (50 mm) to "X" this is the total dimension of the vents. See Figure 5-4.
- Mark dimension from above on outer aluminum intake vent. Measure length of waste material, and transfer dimension to inner grey flue pipe.
- Remove waste from both vents (flue and air). Verify cut ends are square and free from burrs. Insert flue back into intake air vent and pass them through hole in wall.
- Check all measurements before cutting. Clearance to combustible materials is zero when using coaxial vent system.
- After installing venting use calibrated analyzer to verify there is no recirculation of combustion.
- Ensure termination is positioned with slots at the bottom.


Figure 5-2 - Coaxial Screw Placement



! WARNING

Asphyxiation hazard. Before securing the screws ensure the pipe has been pushed in a minimum of 1-3/4" (45 mm) into the gasket end of the other pipe. Failure to follow these instructions could result in death or serious injury.

FIGURE 5-3 - Coaxial Venting Horizontal or Vertical CAN BE USED ON ALL SIZES



WT = Wall Thickness
(2" is insertion depth of straight pipe to elbow)

5.7 Coaxial Vent Screw Placement - See Figure 5-2

Two (2) screws shall be fastened through the outer intake pipe behind the gaskets at equal distances, approximately 180° apart. Note the screws used must be no larger than No. 8-3/4 sheet metal screws and must be zinc coated.

5 - COMBUSTION AIR AND VENT PIPING

FIGURE 5-4 Roof Mount Coaxial Venting
CAN BE USED ON ALL SIZES




FIGURE 5-6 Side Wall Coaxial Venting
CAN BE USED ON ALL SIZES




FIGURE 5-5 - Coaxial Vertical Exhaust - *Multiple Appliances*
CAN BE USED ON ALL SIZES





FIGURE 5-7 - Coaxial Horizontal Exhaust - *Multiple Appliances*
CAN BE USED ON ALL SIZES



⚠ WARNING

Asphyxiation hazard! Improper installation could result in death or serious injury. Read Twin Pipe Installation Instructions completely and understand all requirements before beginning installation.

5.8 Twin Pipe Systems

Twin pipe venting allows exhaust flue and intake flue to be separated from each other. Fresh air is drawn in at a different area from the flue terminal location.

A. Twin Pipe CPVC System

CPVC is approved for boiler exhaust. CPVC or PVC are both approved for air intake.

To transition from Coaxial at the top of the boiler to Twin Pipe CPVC/PVC, adapter kit is available.

B. Twin Pipe Polypropylene System

Single wall polypropylene is used for both exhaust and air intake piping.

To transition from Coaxial at the top of the boiler to Twin Pipe polypropylene venting an adapter kit is available.

C. Twin Pipe Separated Flue

Exhaust and combustion air intake are not located in same general location.

D. Twin Pipe - Common Atmospheric Zone Termination

Exhaust and combustion air intake are located in same general location and are of equal length.

FIGURE 5-8 - 3" / 80 mm Twin Pipe Separated Horizontal Flue Termination




FIGURE 5-9 - 3" / 80 mm Twin Pipe Separated Horizontal Flue Termination -





FIGURE 5-10 - 2" / 50 mm & 3" / 80 mm Twin Pipe Separated Horizontal Flue Termination With Tee On Exhaust CAN BE USED ON ALL SIZES



| Twin Pipe Vent Lengths (Includes first elbow and termination) | | | | |
|--|-------|---------------|---------------|---------|
| Boiler Size | | 125/150 | | |
| Vent Size | | 3" [80 mm] | 2" [50 mm] | All |
| | | Maximum | | Minimum |
| Intake Vent | L1 | 49 ft [15m] | 85 ft | 6 ft |
| Exhaust Vent | L2 | 147 ft [45 m] | [25.9 m] | [1.8 m] |
| Combined Vent | L1+L2 | 196 ft [60 m] | 170 ft | 12 ft. |
| | | | [51.8 m] | [3.6m] |

Single Wall Elbows - Equivalent Length

| | 3" | 2" |
|----------|------------------|---------------|
| 45° bend | 0.82 ft [0.25 m] | 3 ft [0.91 m] |
| 90° bend | 1.64 ft [0.50 m] | 5 ft [1.5 m] |

NOTE: Two pipe can be installed horizontally or vertically.

Grade, Snow & Ice

Maintain 12" (305 mm) US, 18" (457 mm) Canada clearance above highest anticipated snow level, 24" (610 mm) above roof.

Avoid locations where snow may drift and block vent and combustion air. Ice or snow may cause boiler to shut down if vent or combustion air becomes obstructed.


⚠ WARNING

Asphyxiation hazard! Improper installation could result in death or serious injury. Read Twin Pipe Installation Instructions completely and understand all requirements before beginning installation.

NOTICE

Venting manufacturer's use a device to secure single wall twin pipe polypropylene vent pieces to each other. Proper application of the securing mechanism is necessary for any use of twin pipe polypropylene venting on exhaust or air intake. Securing mechanism is for indoor use only and should not be used in outdoor applications. Follow venting manufacturer's instructions for applying the securing mechanism on twin pipe polypropylene venting.

Figure 5-11 - Natalini Clamp



5.9 Securing Twin Pipe Polypropylene Venting

Example for Natalini venting system.

(For other venting system suppliers see their instructions.)

1. Place clamp so etched "UP" is facing up.
2. Open clamp slightly by separating circular areas from each other.
3. Slide male end of first pipe through open clamp so the shoulder of the female end of the pipe stops the clamp from sliding off the pipe.
4. Insert the male end of the second pipe into the clamp on the "up" etched side. Force the two pipes together.
5. Verify the two pipes are secure together with clamp in place.

5 - COMBUSTION AIR AND VENT PIPING

| | |
|--------------------------|--|
| Roof Terminations | <ul style="list-style-type: none"> • 12" (305 mm) Min. horizontal separation between combustion air intake and vent of same appliance. • 12" (305 mm) Min. 84" (2.2 m) Max. vertical separation between combustion air intake and vent of different appliances. • 15" (381 mm) Max. horizontal length of vent. • Min. vent/intake between different appliances 12" (305 mm). • Max. allowable total vertical vent length with outside exposure is 10 ft. (3.05 m). • Abandoned unused masonry chimney may be used as chaseway for combustion air and vent. Both combustion air and vent pipe must exit above top of chimney with clearances as shown in Figure 5-14. |
|--------------------------|--|

FIGURE 5-14 - (2" / 50 mm & 3" / 80 mm) Twin Pipe Roof Vent CAN BE USED ON ALL SIZES




FIGURE 5-12 - Twin Pipe on Roof Combustion Air On Sidewall CAN BE USED ON ALL SIZES




FIGURE 5-15 - (3" / 80 mm ONLY) Single Wall Exhaust Kit and Air Intake Minimum Distance Center to Center




FIGURE 5-13 - Twin Pipe Flue On Sidewall, Combustion Air On Roof CAN BE USED ON ALL SIZES





FIGURE 5-16 - (3" / 80 mm ONLY) Horizontal Twin Pipe, Exhaust and Intake



5 - COMBUSTION AIR AND VENT PIPING

FIGURE 5-17 - (3" / 80 mm ONLY) Twin Pipe Side Wall Vent (Multiple Appliances)




FIGURE 5-20 - 2" / 50 mm & 3" / 80 mm Vent Pipe with T CAN BE USED ON ALL SIZES




FIGURE 5-21 - 2" / 50 mm & 3" / 80 mm Vent Pipe with Tee CAN BE USED ON ALL SIZES




FIGURE 5-18 - (3" / 80 mm ONLY) Twin Pipe Side Wall with 45° Vent




FIGURE 5-22 - 2" / 50 mm & 3" / 80 mm Twin Pipe Side Wall Vent CAN BE USED ON ALL SIZES




FIGURE 5-19 - (3" / 80 mm ONLY) Twin Pipe Side Wall Vent





FIGURE 5-23 - 2" / 50 mm & 3" / 80 mm Twin Pipe Side Wall Vent CAN BE USED ON ALL SIZES



5.10 (3" /80 mm Only) Flexible Vent System

| Flexible Pipe Vent Lengths | | | |
|----------------------------|---------|--------------------------|----------------|
| Boiler Size | | 125/150 | |
| Vent Size | | 3" [80 mm] Diameter Pipe | |
| Minimum | | Minimum | Maximum |
| Natalini | Exhaust | 6 ft [1.8 m] | 75 ft [22.8 m] |
| | Intake | 6 ft [1.8 m] | 50 ft [15.2 m] |
| DuraVent® | Exhaust | 6 ft [1.8 m] | 82 ft [24.9 m] |
| | Intake | 6 ft [1.8 m] | 50 ft [15.2 m] |
| Centrotherm | Exhaust | 6 ft [1.8 m] | 52 ft [15.8 m] |
| | Intake | 6 ft [1.8 m] | 50 ft [15.2 m] |
| Z-Dens | Exhaust | NA | NA |
| | Intake | NA | NA |

Single Wall Elbows - Equivalent Length


| | |
|-----------------|------------------|
| | 3" [80 mm] |
| 45° bend | 0.82 ft [0.25 m] |
| 90° bend | 1.64 ft [0.50 m] |

NOTICE

Flexible vent systems shall only be run vertical. Horizontal runs before adapting to flexible must be rigid pipe.

- Maximum vent lengths based on equivalent straight runs only. Include rigid pipe and fittings in overall equivalent length calculations.
- Flexible venting installations use single wall polypropylene to pass flue gasses to base of chimney, then flexible venting to get them to termination at the top.
- Combustion air is not supplied through masonry chimney. Combustion air must be from outside using 3" [80 mm] single wall polypropylene.
- Position boiler to use minimum of rigid single wall polypropylene venting to the chimney.
- Follow venting manufacturer's instructions on assembly and clearances to maintain.
- Avoid sharp bends in flexible venting.

FIGURE 5-24 - (3" / 80 mm Only) Flexible Venting System CAN BE USED ON ALL SIZES




5 - COMBUSTION AIR AND VENT PIPING

FIGURE 5-25 - Flue Terminal Location

All vent pipe and combustion air pipe and fittings shall comply with the following:

Use only manufacturer approved venting materials or venting materials primer and glue approved to: ULC S636 in Canada, or UL 1738 in the U.S.

Materials used in the U.S. shall comply with Authority having jurisdiction and in absence of such with: ANSI/ASTM D1785, ANSI/ASTM F441, ANSI/ASTM F493.




Vent Termination Minimum Clearances

| | | US Installations | Canadian Installations |
|---|---|---|------------------------|
| A | Clearance above grade, veranda, porch, deck, or balcony | 12" (305 mm) | 12" (305 mm) |
| B | Clearance to window or door that may be opened | 12" (305 mm) | 3 ft. (0.9 m) |
| C | Clearance to permanently closed window | *12" (305 mm) | *12" (305 mm) |
| D | Vertical Clearance to ventilated soffit located above the terminal within a horizontal distance of 2 feet (610 mm) from the center line of the terminal | 18" (457 mm) | 18" (457 mm) |
| E | Clearance to unventilated soffit | 18" (457 mm) | 18" (457 mm) |
| F | Clearance to outside corner | 9" (229 mm) | 9" (229 mm) |
| G | Clearance to inside corner | 36" (456 mm) | 36" (456 mm) |
| H | Clearance to each side of center line extended above meter/ regulator assembly | 3 ft. (0.9 m) within a height of 15 ft. (4.5 m) above the meter/ regulator assembly | 3 ft. (0.9 m) |
| I | Clearance to service regulator vent outlet | 3 ft. (0.9 m) | 3 ft. (0.9 m) |
| J | Clearance to non-mechanical air supply inlet to building or the combustion air inlet to any other appliance | 12" (305 mm) | 3 ft. (0.9 m) |
| K | Clearance to mechanical air supply inlet | *3 ft. (0.9 m) | 6 ft. (1.8 m) |
| L | Clearance above paved sidewalk or paved driveway located on public property | *7 ft. (2.1 m) | 7 ft. (2.1 m) † |
| M | Clearance under veranda, porch, deck or balcony | *12" (305 mm) ‡ | 12" (305 mm) ‡ |
| † A vent shall not terminate directly above a sidewalk or paved driveway that is located between two single family dwellings and serves both dwellings. | | *For clearances not specified in ANSI Z223.1/NFPA 54 or CSA B149.1, clearance will be in accordance with local installation codes and the requirements of the gas supplier and these installation instructions. | |
| ‡ Permitted only if veranda, porch, deck or balcony is fully open on a minimum of one side beneath the floor. | | | |

Note: Local Codes or Regulations may require different clearances. Flue terminal must be exposed to external air and position must allow the free passage of air across it at all times. In certain weather conditions the terminal may emit a plume of steam. Avoid positioning terminal where this may cause a nuisance.

FIGURE 5-26 - Condensate Drain



5.11 Condensate Piping

- Use materials acceptable to authority having jurisdiction. In absence of such authority:
 - USA - PVC or CPVC per ASTM D1785/D2845 Cement or primer per ASME D2564 or F493.
 -
- No external trap needed.
- Connect condensate hose, hose clamps, and coupling to boiler drain trap as shown in figure 5-28.
- Connect condensate piping to 3/4" PVC for 125/150 as shown.
- Slope condensate drain pipe minimum 1/4" per foot (21 mm/m) away from boiler.
- Support condensate pipe to eliminate any sags.
- Use field source condensate pump, designated for use with condensing boiler, if boiler located below disposal point.
- Condensate pump should have overflow switch. Condensate from Boiler is slightly acidic and may cause property damage if overflow.
- Field source condensate neutralizing kit as required by authority having jurisdiction or for environmentally friendly condensate disposal.

NOTICE

Manufacturer requires an air vent be used to prevent condensate line vacuum lock.

⚠ WARNING

- Poison hazard. Ethylene glycol is toxic. Do not use ethylene glycol.
- Never use automotive or standard glycol antifreeze, even ethylene glycol made for hydronic systems.
- Ethylene glycol can attack gaskets and seals used in hydronic systems.
- Do not use petroleum based cleaning or sealing compounds boiler system.
- Do not fill boiler or boiler system with softened water.
- Use only inhibited propylene glycol solutions certified by fluid manufacturer as acceptable for use with closed water heating system.
- Thoroughly clean and flush any system that used glycol before installing new Boiler.
- Provide user with Material Safety Data Sheet (MSDS) on fluid used.

NOTICE

Boiler rated at 50 psig (345 kPa) maximum allowable working pressure. Boiler provided with 30 psig (206 kPa) safety relief valve.

NOTICE

System pressure above 43 psi [2.96 bar] **WILL** result in boiler shutting down.

6.1 General

- Primary/Secondary piping required by manufacturer.
- Install piping in accordance with authority having jurisdiction.
- Support system piping and safety relief valve discharge piping. Boiler's internal piping can be damaged if subjected to excessive weight.

NOTICE

The intended use of the internal heat exchanger pump is a boiler loop. Do not use as a primary system pump.

- Size central heating pump (and domestic hot water pump, if used) for system requirements only. Internal heat exchanger pump compensates for pressure drop through boiler internal piping and heat exchanger.
- Thoroughly clean and flush system before connecting to boiler.
- If oil is present in system water, use approved detergent to wash system.

- It is necessary to semi-annually check the water quality of central heating systems.
- Manufacturer recommends installation of magnetic dirt separator in the hydronic system where there are cast iron or steel components, or where the previous boiler was a cast iron heat exchanger. The abrasive, extremely fine sediment is difficult to remove and can deposit onto heat exchange surfaces and accumulate in pump cavities causing reduced efficiency and premature wear.
- Flush system to remove any solid objects such as metal chips, fibers, or Teflon tape, etc.
- Flush system until water runs clean and piping is free of sediment.
- Use purge valve to flush zoned systems, each zone separately. If purge valves and isolation valves are not installed, install them to properly clean the system.
- When purging installations that include standing iron radiators and systems with manual vents at high points, start with nearest manual air vent. Open the vent until water flows out, then close vent. Repeat this procedure, working toward furthest air vent.
- Install a basket strainer if large amounts of sediment is present. Keep basket clear of sediment build up.
- Ensure piping in the heating system has an oxygen barrier.

6.2 Special Conditions**NOTICE**

Do not expose boiler and condensate piping to freezing temperatures.

- System piping exposed to freezing conditions: Use inhibited propylene glycol solutions certified by fluid manufacturer for use with closed water heating system. Do not use automotive or ethylene glycol.
- Boiler installed above radiation level (or as required by authority having jurisdiction). Integral low water pressure switch is provided in boiler.
- Boiler used in connection with refrigeration system. Install piping in parallel with boiler, with appropriate valves to prevent chilled medium from entering boiler.
- System piping connected to heating coils located in air handling unit exposed to refrigerated air circulation. Install flow control valves or other automatic means to prevent gravity circulation of boiler water during cooling cycle.

⚠ WARNING

Burn and scald hazard. Safety relief valve could discharge steam or hot water during operation. Use pipe suitable for temperatures of 375°F (191°C) or greater. DO NOT use plastic pipe. Install discharge piping per these instructions.

NOTICE

When installing safety relief valve it must be installed in a vertical position with spindle at top.


6.3 Safety Relief Valve and Air Vent

- Install safety relief valve using pipe fitting provided with boiler. See Figure 6-1.
- Install safety relief valve with spindle in vertical position.
- Do not install shutoff valve between boiler and safety relief valve.
- Install discharge piping from safety relief valve. Do not use plastic pipe.
- Use ¾" or larger pipe.
- Use pipe suitable for temperatures of 375°F (191°C) or greater. Do not use plastic pipe on safety relief valve.
- Individual boiler discharge piping shall be independent of other discharge piping.
- Size and arrange discharge piping to avoid reducing safety relief valve relieving capacity below minimum relief valve capacity stated on rating plate.
- Run pipe as short and straight as possible to location protecting user from scalding and properly drain piping.
- Install union, if used, close to safety relief valve outlet.
- Install elbow(s), if used, close to safety relief valve outlet and downstream of union (if used).
- Terminate pipe with plain end (not threaded).

6.4 Trim Piping

- Temperature - Pressure Gauge. Install temperature pressure gauge in near boiler piping on supply side.
- Some boiler models may have integral drain valve located inside jacket directly underneath pump. Install external drain valve as required.

FIGURE 6-1 Safety Relief Valve




6.5 System Piping

- See Figure 6-6 for basic system piping configurations.
- Systems with automatic fill valves require back flow prevention device.
- Single boiler system. See Figures 6-5, 6-6, for general guidance. Additional considerations:
 - Boiler control only supports integrated pump. Installer responsible for integration of multiple central heating pumps using field supplied external control.
 - Boiler control allows domestic hot water prioritization.
- Thoroughly flush all hydronic piping.
- Secure all valves/fittings to boiler.
- Route pressure relief valve discharge piping to the floor. Follow local code with respect to necessary distance to the floor. See Figure 6-1.
- Verify all drain valves are closed.

FIGURE 6-2 - Piping Diagram - LWCO Location

Note → Arrange piping to prevent water dripping onto boiler.

Note → Illustrations are meant to show system piping concept only. Installer is responsible for all equipment and detailing required by authority having jurisdiction.



* Check Local Codes for Maximum Distance to Floor.

Note → **1** DO NOT PLACE ISOLATION VALVE BEFORE TEE OR LWCO.

6.6 External Optional Low Water Cut Off

These guidelines are supplied when necessary to install an additional Low Water Cut Off (LWCO), for sensing a low water level condition in a boiler, as required by the Authority Having Jurisdiction.

Follow LWCO manufacturer installation instructions for type of LWCO selected in addition to these instructions.

LWCO shall be 120V/60HZ control and dry contacts sized for load being connected. Wire control to boiler. See Figure 6-4.

Connect LWCO device to the system ground. Ground in accordance with the requirements of the authority having jurisdiction or, in the absence of such requirements, with the National Electrical Code (NEC) or Canadian Electrical Code CEC.

- Locate LWCO sensing device in the supply piping, above the minimum height of boiler. See Figure 6-2, Piping Diagram.
- Position control in HORIZONTAL piping to assure proper boiler protection (upright or 90° rotation).
- For proper operation, sensing element of the LWCO control shall be positioned in the tee to sense the main water stream. Maintain minimum 1/4" spacing from pipe walls. Element shall NOT contact the rear, or side walls of the tee. See Figure 6-3.
- Install an air vent using a tee to avoid nuisance shutdowns.
- Apply small amount of pipe sealant to threaded connections.
- Arrange piping to prevent water dripping onto boiler.
- DO NOT install water shutoff valve between boiler and LWCO sensing device.

FIGURE 6-3 - Low Water Cutoff - Detail








FIGURE 6-4 - LWCO Wiring Diagram



6.5 Manufacturer Recommendation - Strainer



Manufacturer Recommendation

Manufacturer strongly recommends the use of a strainer filtering potable water before entering the boiler. The strainer prevents any sedimentation and debris from your water supply piping from entering the boiler. Debris carried from the water supply will clog DHW water flow sensor, potentially resulting in significant operation issues.

Locate the strainer as close to the boiler as possible and place on DHW (domestic hot water) inlet connection located at bottom of the boiler.

6.7 Central Heating System

Boiler is designed for use in a sealed central heating system. Design the system to operate with flow temperatures of up to 176°F (80° C), take pump head, expansion tank size, mean radiator temperature, etc. into account.

Boiler is supplied with the following components: Pressure relief valve - 30.0 psi (2.1 bar). Boiler internal pressure switch will shut boiler off below 7.5 psi / 0.5 bar and above 43.5 psi / 3.0 bar.

Pressure gauge - to indicate the system pressure to be maintained.

6.8 Domestic Hot Water Mode

Dunkirk Boiler DCCF-150 and DCBF-125 with indirect

⚠ WARNING

Burn, Scald Hazard! Water temperature over 125°F (51°C) can cause severe burns and scalding. See User's Manual before setting water temperature. Failure to follow these instructions could result in death or serious injury.

tank

- Priority is given to the domestic hot water supply. Demand at tap or shower will override any central heating requirement.
- Flow of water will operate the DHW flow switch which requests the 3 way valve to change position. This will allow

the pump to circulate the primary water through the DHW plate heat exchanger. (DCCF 150 only)

- Combustion fan will then come on and begin to run at ignition speed.
- Once the fan reaches ignition speed the control board will allow power to flow to the spark generator and gas valve creating ignition in the combustion chamber. The flame sensor will acknowledge the presence of the flame in the combustion chamber and send a signal to the control board.
- Temperature sensors will send a signal to the control board allowing the control board to increase/ decrease the speed of the fan. The combustion fan will in turn modulate the gas rate accordingly.
- When the domestic hot water demand ceases the burner will extinguish, unless there is a demand for central heating.

6.9 Frost Protection Mode


Frost protection mode is integrated into the appliance when electricity is connected to the boiler, regardless if power is "on" or "off".

If temperature falls below 41°F / 5° C boiler will fire on its minimum setting until flow temperature of 86°F / 30° C is reached.

6.10 Pump Protection

Pump will automatically operate for 1 minute in every 24 hours to prevent seizing.

FIGURE 6-6



7 - GAS SUPPLY PIPING

DANGER

Fire Hazard. Do not use matches, candles, open flames, or other methods providing ignition source. Failure to comply will result in death or serious injury.

WARNING

Fire, explosion, asphyxiation and burn hazard. Boiler piping and gas connections shall be leak tested before placing boiler in operation. Failure to follow these instructions and or improper installation could result in death or serious injury.

WARNING

If overheating occurs or gas supply fails to shut off, do not turn off or disconnect the electrical supply to the pump. Shut off gas supply at a location external to the appliance.

Do not use this boiler if any part has been under water. Call a qualified service technician before use.

CAUTION

WHAT TO DO IF YOU SMELL GAS

- Do not try to light any appliance.
- Do not touch any electrical switch; do not use any phone in your building.
- Immediately call your gas supplier from a neighbor's phone. Follow gas supplier's instructions.
- If you cannot reach your gas supplier, call the fire department.

NOTICE

If overheating occurs or gas supply fails to shut off, do not turn off or disconnect electrical supply to pump. Shut off gas supply at location external to the boiler.

NOTICE

Use of CSA approved corrugated, semi-rigid stainless steel tubing with polyethylene jacketing is approved for use with boilers following tubing manufacturer's instructions.

Use of flexible "appliance whip" gas tubing is not allowed per NFPA 54.

Required Gas Supply Pressure

| Natural Gas | | Liquid Propane | |
|-------------|------------|----------------|------------|
| Min. | Max. | Min. | Max. |
| 3.5" w.c. | 10.5" w.c. | 8.0" w.c. | 13.0" w.c. |
| (0.87 kPa) | (2.61 kPa) | (1.99 kPa) | (3.23 kPa) |

7.1 General

- Use piping materials and joining methods acceptable to authority having jurisdiction. In absence of such requirements:
 - USA - National Fuel Gas Code, ANSI Z223.1/NFPA 54

- Install manual main shutoff valve before the gas valve accordance with state and local requirements.
- Size and install gas piping system to provide sufficient gas supply to meet maximum input at not less than minimum supply pressure.
- Boiler and its individual shutoff valve shall be disconnected from gas supply piping system during any pressure testing of that system at test pressures in excess of 1/2 psi (3.40 kPa - 34.47 mbar).

Gas Supply Required

| Model | Natural Gas (A) | Liquid Propane (E) |
|----------|---|---|
| DCBF-125 | 118 ft ³ /h (3.30m ³ /h) | 51 ft ³ /h (1.48m ³ /h) |
| DCCF-150 | 143 ft ³ /h (4.00 m ³ /h) | 61.15 ft ³ /h (1.72 m ³ /h) |

- Boiler shall be isolated from the gas supply piping system by closing its individual manual shutoff valve during any pressure testing of gas supply piping system at test pressures equal to or less than 1/2 psi (3.5 kPa).
- Install boiler so that gas ignition system components are protected from water (dripping, spraying, rain, etc.) during appliance operation and service (circulator replacement, condensate trap, control replacement, etc.).
- Gas meter and supply pipes must be capable of delivering the listed quantity of gas in addition to demand from any other appliances in the house. Boiler requires a 3/4" (19.5 mm) gas supply pipe.
- Support piping with hooks straps, bands, brackets, hangers, or building structure components to prevent or dampen excessive vibrations and prevent strain on gas connection. Boiler will not support piping weight.
- Use thread (joint) compound (pipe dope) suitable for liquefied petroleum gas.
- Install external field sourced manual main gas shutoff valve, ground joint union, and sediment trap upstream of gas controls. See Figure 7-1.
- Install boiler so gas ignition system components are protected from water dripping, spraying, rain, etc. During appliance operation and service.
- Leak test boiler and gas line connections before placing boiler into operation.

NOTICE

Sediment trap shall be located upstream of gas controls.

NOTICE

If overheating occurs or gas supply fails to shut off, do not turn off or disconnect electrical supply to pump. Shut off gas supply at location external to the boiler.

7.2 Leak Check Gas Piping

Pressure test boiler and gas connection before placing boiler in operation.

- Pressure test over 1/2 psig (3.5 kPa). Disconnect boiler and its individual gas shutoff valve from gas supply system.
- Pressure test at 1/2 psig (3.5 kPa) or less. Isolate boiler from gas supply system by closing manual gas shutoff valve.
- Locate leakage using gas detector, noncorrosive detection fluid, or other leak detection method acceptable to authority having jurisdiction. Do not use matches, candles, open flames, or other methods that can provide ignition source.
- Correct leaks immediately and retest.

7.3 Gas Orifice - See Figure 7-2

Models 125, 150 - = 5.8 mm (Natural & LP)

Figure 7-1 - Gas Piping





FIGURE 7-2 Gas Orifice Location



8 - ELECTRICAL CONNECTIONS

⚠ DANGER

Electrocution Hazard! HIGH VOLTAGE - Connections in terminal block M1 are high voltage (120V / 60Hz). Before making connections, verify appliance is disconnected from power supply. Respect the input polarity on terminal block M1: L (LINE) - N (NEUTRAL). Failure to follow these instructions WILL result in death or serious injury.

⚠ WARNING

Electrical shock hazard. Turn OFF electrical power supply at service panel before making electrical connections. Failure to do so could result in death or serious injury.

8.1 General

Electrically bond boiler to ground in accordance with requirements of authority having jurisdiction or in absence of such requirements refer to:

- USA- National Electrical Code, ANSI/NFPA 70.
- Install all wiring in accordance with requirements of National Electrical Code and any additional national, state, or local code requirements having jurisdiction.

8.2 Install Room Thermostat

Install room thermostat on inside wall. Do not install where it will be influenced by drafts, hot or cold water pipes, lighting fixtures, television, sun rays or near a fireplace.

8.3 Electrical Connections


- Boiler requires 120V 60Hz power supply. Verify electrical supply is polarized.
- Boiler shall be grounded and on dedicated circuit.
- Shall be one common isolator, providing electrical isolation for boiler and any external controls. Using PVC insulated cable 18 AWGx3C 221°F (105°C).
- All wiring must be installed in accordance with requirements of the National Electrical Code and any additional national, state, or local code requirements having jurisdiction. All wiring must be N.E.C. Class 1.
- Canada, installation must conform to CSA C22.1 Canadian Electrical Code Part 1 and any local codes.
- If replacing original boiler wiring use only TEW 105°C or equivalent.
- If appliance is connected to in floor system, install limit thermostat to prevent latter from overheating.

| Model Size | 125 | 150 |
|------------------------|-------------------------------------|-------|
| Power Supply | 120V - 60Hz | |
| Power Consumption | 133 W | 142 W |
| Internal Fuse (Qty. 2) | F3.15 A | |
| Electrode Spark Gap | 1/8" to 3/16" [3.1 mm to 4.7 mm] | |

Note

Wiring diagrams can be found in Appendix A of this Manual.

FIGURE 8-2 Junction Box Left side of Boiler



Junction Box
with Knockouts
and grommets

⚠ DANGER

Electrocution Hazard! HIGH VOLTAGE - Connections in terminal block M1 are high voltage (120V / 60Hz). Before making connections, verify appliance is disconnected from power supply. Respect the input polarity on terminal block M1: L (LINE) - N (NEUTRAL). Failure to follow these instructions WILL result in death or serious injury.

8.4 Access To Connection Block

1. Ensure there is no line voltage at boiler.
2. Lift and remove front cover. Remove screws (2) from cover on junction box located on boiler's left side. Remove junction box cover.
3. Guide controller or thermostat wire through round grommet(s) located in the junction box on boiler's left side.
4. Tilt control box forward by opening holding clip located on left side of control housing.
5. Expose M1 and M2 terminal blocks by removing screw from plastic cover on left. See Figure 8-3.
6. Remove plastic from channel in plastic cover. Run wires through new opening.
7. Connect wires to appropriate terminals on connection block.
8. Tilt control box back to original position. Ensure clip on left side of control box is fully engaged.
9. Replace front cover and cover to junction box.
10. Turn power to boiler on.

Dry contact end switches from various manufacturers can be attached to boiler control PCB.

8.5 Main Supply Connection

Main supply is connected to terminal block **M1** which is high voltage (120V / 60Hz).

Fuses, 3.15 A, are incorporated in the power supply terminal block. To check or replace fuse pull out black fuse carrier.

TERMINAL BLOCK M1

- (L) = Live (brown)
- (N) = Neutral (light blue).
- = Ground (yellow-green).
- (1) (2) = contact for 120V Room Thermostat.

Place jumper back on terminals 1-2 of boiler terminal block **M1** if room thermostat is not used or if Remote Control is not installed.

FIGURE 8-2 Terminal Block Locations





FIGURE 8-3 Terminal Plastic Cover with Knockouts



TERMINAL BLOCK M2

Terminals 1 - 2: Open Therm connection of programmable room unit (supplied as accessory)

Terminals 4 - 5: outdoor temperature sensor connection (supplied as accessory)

Terminal 3: not used.

Terminals 6 - 7 - 8: see section 8.6.

Terminals 9 - 10: Indirect storage tank connection for Dunkirk Models DCBF-125.

8 - ELECTRICAL CONNECTIONS

8.6 Install Room End Switch

Install room end switch on inside wall. Do not install where it will be influenced by drafts, hot or cold water pipes, lighting fixtures, television, sun rays or near a fireplace.

Dry contact only - do not apply 24 volts between 6 and 7.

A. Connect Room End Switch

- turn power off to boiler;
- access terminal block **M2**;
- connect room end switch to terminals **6(R)-7(W)-8(C)**; Do not apply dry volt between 2 terminals. Dry contact only.
- turn boiler power on;
- verify room end switch operates per end switch manufacturer's instructions.

NOTE: maximum load allowed is 10 mA

Dry contact end switches from various manufacturers can be attached to boiler control PCB.

8.7 Optional Electrical Connections

A. 1K Ohm (1K Ω) Outdoor Temperature Sensor

To connect this accessory, see figure 8-5, terminals 4-5, and instructions supplied with **1K Ω** sensor.

B. Setting "Kt" Climate Curve

When external **1K Ω** sensor is connected to boiler, the electronic board adjusts the flow temperature calculated according to set Kt coefficient.




Select required curve by pressing   as indicated in chart below for selecting the appropriate curve (00 to 90).



FIGURE 8-6 Kt Climate Curves



NOTE: Temperatures below -40 °F (-40 °C), maximum heating flow temperature set point no longer increases, curves shown on graph become horizontal.

Boiler setpoint will override sensor setpoint.

FIGURE 8-4 Thermostat Connections





FIGURE 8-5 Outdoor Sensor Connections





NOTICE

Sensors used for this boiler are proprietary to the manufacturer. Use of after market sensors will diminish boiler performance.

8.8 Indirect Storage Tank

Boilers DCBF-125 can be electrically connected to indirect storage tank as follows:


- Connect DHW priority **10K Ω** sensor NTC to terminals **9-10** on terminal block **M2**.
- Insert **10K Ω** NTC sensor element in the sensor well of indirect storage tank.
- Verify exchange capacity of the storage boiler coil is appropriate for boiler power.
- Adjust DHW temperature +95 °F...+140 °F (+35 °C...+60 °C) by pressing   on boiler Control.

IMPORTANT: set parameter P03 = 05 as described in: "PARAMETER SETTINGS".

Note Sensors used for this boiler are proprietary to the manufacturer. Use of after market sensors will diminish boiler performance.

FIGURE 8-7A Kt Indirect Storage Tank

*125 Model shown




| | |
|----------|--|
| A | Heating system |
| B | Three way diverter valve |
| C | Heating water flow |
| D | Heating supply to DHW indirect storage tank coil |
| E | Heating water return |
| F | Tank |
| G | Optional 10k Ω DHW priority sensor tank |

9 - START UP PROCEDURE


9.1 Central Heating System Connections - Heat Only

9.2 Central Heating System Connections - Combi

DCBF-125 HEATING ONLY WITH OPTIONAL INDIRECT DHW CONNECTION




DCBF-125 HEATING ONLY WITHOUT OPTIONAL INDIRECT DHW CONNECTION



| LEGEND | | 125 |
|--------|---|-----------|
| A | Heating supply connection | 1¼" sweat |
| B | Drain Connection for condensate | ¾" NPT |
| C | Gas shutoff connection | ¾" NPT |
| D | Optional Indirect DHW connection (may exit right or left) | ¾" sweat |
| E | Heating return connection | 1¼" sweat |

DCCF-150 COMBI



| LEGEND | | 150 |
|--------|---------------------------------|-----------|
| A | Heating supply connection | 1¼" sweat |
| B | DHW outlet | ½" sweat |
| C | Drain connection for condensate | ¾" NPT |
| D | Gas shutoff connection | ¾" NPT |
| E | Cold DHW inlet tap | ½" sweat |
| F | Heating return connection | 1¼" sweat |

9.3 System Start Up


Follow all codes and regulations when filling the boiler.

Use drain taps to allow system to completely drain.

Thoroughly flush the heating system before boiler is connected and again after first heating season.

- Boiler is fitted with automatic air vent positioned on pump Vent and is fitted with adjustable sealing cap. See Figure 9-1.
- Open central heating flow and return valves. Spindle is flat in-line with valve.
- Open fill point valve on filling system until water begins to flow. To aid venting boiler drain may be open until water flows out. Close drain as soon as water appears.
- Systems using radiators to remove air - Vent each radiator in turn, starting with lowest in the system.
- It is important the pump is properly vented to avoid running it dry and damaging its bearings. Unscrew and remove cap from center of pump. Use screwdriver. Rotate exposed spindle about half turn, replace cap.
- Check operation of heating pressure relief valve. Pull lever on top of valve upwards lifting the seat. This will allow water to escape from system. Check water is escaping from the system.
- Open cold water supply inlet valve. Turn on all domestic hot water taps. Allow water to flow until no air is present. Turn off domestic hot water taps. See page 4- Physical Data and section 2.7 Operational Features.

FIGURE 9-1 Condensate Drain Assembly



9.4 Fill Condensate Trap with Water

WARNING

Asphyxiation hazard! Fill condensate trap before starting boiler to avoid combustion products escaping boiler. Failure to follow these instructions could result in death or serious injury.

- To fill the condensate trap pour water into exhaust vent until water begins to flow through the siphon.
- Visually inspect the siphon to ensure it is full with clean water.
- During operation check condensate trap to ensure it draining properly.

Note Condensate trap must be manually filled with water at initial start up.

9 - START UP PROCEDURE

9.5 Control Panel

Press and hold **iIP** for 1 second, to display information as shown in the table below.

Press **⏻/R** to exit.

| i | DESCRIPTION | i | DESCRIPTION |
|----------|--|----------|---|
| 00 | Secondary fault internal code | 09 | Setpoint Central Heating (°F/°C) |
| 01 | Heating flow temperature (°F/°C) | 10/11 | Manufacturing information |
| 02 | Outdoor temperature (°F/°C) | 12 | Flue sensor temperature (°F/°C) |
| 03 | Indirect Tank DHW temperature (boiler CH only) | 13 | Manufacturing information |
| 04 | Domestic hot water temperature (boiler with plate exchanger) | 14 | Identification Open Therm communication |
| 05 | Water pressure in heating system (PSI/bar) | 15 | Manufacturing information |
| 06 | Heating return temperature (°F/°C) | 16 | Manufacturing information |
| 07 | Thermo fuse status (000/001) | 17 | Fan speed ("i17"x100) |
| 08 | Not used | 18 | Manufacturing information |

BUTTONS Key

| | |
|--|--|
| | DHW temperature adjustment (+ to increase the temperature and - to decrease it) |
| | Heating water temperature adjustment (+ to increase the temperature and - to decrease it) |
| | Boiler operating information |
| | Operating mode: DHW – DHW & Heating – Heating Only |
| | ON/Off – Reset – Exit menu/functions |



SYMBOL Key

| | | | |
|--|--|---------------------|---------------------------------|
| | Off: heating and DHW disabled (only boiler frost protection is active) | | Burner lit |
| | Ignition fault | | DHW operating mode enabled |
| | Boiler/system water pressure low | | Heating mode enabled |
| | Call a qualified service technician | P | Programming menu |
| | Manually resettable fault () | i | Boiler information menu |
| | Fault in progress | °C, °F, bar, PSI | Set unit of measurement (SI/US) |

NOTICE

All connections shall be made and water added before performing this function.

NOTICE

First ignitions immediately after installation, system will implement a self-learning procedure to reach correct ignition level.

9.6 Prior to Commissioning:

- Check system pressure is correct;
- Power boiler;
- Open gas tap (positioned under boiler);
- Select required heating mode. See section 10.4 Operating Modes.

9.7 Commissioning For The First Time:

1. Turn power to boiler on. Code "000" appears on the display. Appliance is ready for "commissioning" procedure.
2. Press **[M+]** **[iP]** at the same time. Hold for 6 seconds. "On" appears on the display for 2 seconds followed by code "312" indicating "de-aeration" function is active. This function lasts 10 minutes.
3. Boiler will turn on after deaeration function is complete. Display will show code "000" alternating with % of ignition power and temperature value (°F / °C).
 - During this **gas recognition function** phase which lasts about 7 minutes, type of gas being used is analyzed.
 - During this function, assure maximum heat exchange to heating or DHW system (domestic hot water demand) by having all heating zones open or all domestic hot water taps open, in order to prevent boiler from switching off due to overheating.
 - If boiler operates on Gas A (Natural Gas), display shows **NG** (Natural Gas) for about 10 seconds. Boiler is now ready for normal operation.
 - If display shows **LPG** (Gas E), press **[O/R]** and **[iP]** together and hold down for at least 4 seconds to exit without changing factory setting. Boiler will stay set to Natural Gas.
 - If boiler operates on Gas E (LPG) display shows **LPG** (Gas E). Press **[iP]** for at least 6 seconds to confirm gas used.
 - If display shows **NG** (Gas A) and does not recognize the type of gas used, press **[O/R]** and **[iP]** together and hold down for at least 4 seconds to exit the function. Change parameter **P02=01** as described in section 9.12 Parameter Settings of boiler Installation, Operation and Maintenance Manual. Perform Automatic Calibration Function. Manual Calibration may be necessary if combustion is not within specified range.

Note

Boiler must not shutoff during calibration. Open all heating zones in heating or DHW mode to ensure boiler does not shutoff.

9.8 Automatic Calibration Function

Before performing this function verify there are no heat demands in progress.

During this function ensure there is maximum heat exchange to the system in Heating or DHW mode (DHW request) to avoid boiler shutting off due to overheating.

Press **[O/R]** and **[M-]** together and hold for about 6 seconds. When display indicates "On" press **[iP]** within 3 seconds after pressing previous buttons.

NOTICE

Important: If display indicates "303" Automatic Calibration function has not been activated. Disconnect boiler from main power supply for few seconds and repeat procedure.

1. When function is enabled, **[M+]** and **||||** will flash on the display.
2. After ignition sequence, which can also take place after few attempts, boiler performs three operations. Each operation lasts about 1 minute:
 - maximum power
 - ignition power
 - minimum power
3. Before moving to the following phase, from maximum power to ignition power and then to minimum power. **P** and **[M+]** appear on the display.
4. During this phase, power level reached by boiler and delivery temperature alternate on the display.
5. When **[M+]**, **[M-]** and **||||** flash together on the display, automatic calibration function has completed.
6. Press **[O/R]** to exit the function. Display will show **ESC**.
7. Verify combustion is within specified range. If not, perform Automatic and then Manual Calibration. (See Section 9.8)

NOTICE

IMPORTANT: If Calibration function does not complete, verify unit did not shut down for over-temperature. Repeat Automatic Calibration. Replace KEY if Automatic calibration does not complete after second try.

NOTICE

During initial ignition, burner may not ignite. This may cause boiler to shut down until any air in gas pipes is vented. Repeat ignition procedure until gas reaches the burner. To reset boiler operation, press **[O/R]** for at least 2 seconds.

9.9 Manual Calibration Function:

Manual Calibration phase starts at the end of the Automatic Calibration.

The Display shows the boiler power and adjustment of the CO₂ value (parameter setting) during Manual Calibration sequence.

The process begins at minimum power.

- A. After Automatic Calibration sequence with flashing together on the display, you can adjust minimum power combustion by pressing to lower % CO₂, and to raise % CO₂.
- B. When minimum power combustion is in the specified range, press and then to reach ignition power.
- C. Press to adjust ignition power combustion. Press to lower % CO₂, and to raise % CO₂.
- D. When ignition power combustion is in the specified range, press and then to reach maximum power.
- E. Press to adjust maximum power combustion. Press to lower % CO₂, and to raise % CO₂.
- F. When maximum power combustion is in the specified range, press to exit Manual Calibration Function.

IMPORTANT INFORMATION


- A. If gas recognition function is interrupted by power blackout, start function again when power is restored. Press and together and hold at same time for at least 6 seconds.
- B. If display shows fault **E118** (low pressure in hydraulic circuit) during gas recognition function, open filling tap on appliance and restore correct pressure.
- C. If gas recognition function is interrupted due to fault (e.g.: **E133** no gas) press to reset. Then press and (for at least 6 seconds) to restart the function again. If gas recognition function is interrupted due to overheating, restart function by pressing and holding down together for at least 6 seconds.
- D. Combustion of this appliance has been factory controlled, calibrated and set for operation with **Gas A** (Natural Gas).
- E. During Gas Type Control Function, combustion ratio will increase for a short period of time while gas type is being established.

9.10 De-Aeration Function

Used to eliminate air inside the heating circuit when boiler is installed or after maintenance when water is drained from primary circuit.

1. Press buttons together and hold for 6 seconds. **On** appears on display for a few seconds, followed by program row **312**.
2. The electronic board will activate pump on/off cycle for 10 minutes. Function will automatically stop at end of cycle.
3. To manually exit this function, press buttons together and hold for 6 seconds.

FIGURE 9-3 - Gas Inlet Tap - Pi



PI = Gas Supply Inlet Pressure Tap

9.11 Commission Set Up (Gas) - Changing The Type Of Gas

During the **first** installation boiler carries out an automatic commissioning function.

The system is able to detect the gas type present in the network.

Correct gas type setting, is made by pressing two buttons at the same time, see section 9.7 Commissioning.

Change of gas type is made **after** the first installation:

- Change parameter P02. See section 9.7 Commissioning and section 9.13 Parameter Settings.
- Check minimum gas pressure is suitable for selected gas:
 - Gas A (NG) = 3.5" (8.7 mbar)
 - Gas E (LPG) = 8.0" (19.9 mbar)
- Place supplied label with indication of gas type close to the data plate of boiler replacing the original.
- Perform Automatic Calibration Function - **Section 9.8**.
- Manufacturer recommends verification of CO₂ concentration on the flue.

9.12 Chimney Sweep Function (CO₂ Adjust)

For correct boiler operation, content of (CO₂ - O₂) in the combustion flue must be within tolerances indicated in table below.

COMBUSTION TABLE

| | | Gas A (Natural Gas) DCBF-125 | | Gas A (Natural Gas) DCCF- 150 | | Gas E (LPG) | |
|----------------------|-----------------|------------------------------------|------------------|-------------------------------------|------------------|-------------------|------------------|
| | | CO ₂ % | O ₂ % | CO ₂ % | O ₂ % | CO ₂ % | O ₂ % |
| Maximum power (100%) | Nominal value | 8.7 | 5.4 | 9.0 | 4.9 | 10.0 | 6.0 |
| | Permitted value | 8.2 – 9.3 | 6.3 – 4.3 | 8.5 – 9.5 | 5.7 – 4.0 | 9.5 – 10.5 | 6.8 – 5.2 |
| Ignition power (*) | Nominal value | 8.7 | 5.4 | 8.7 | 5.4 | 10.8 | 4.8 |
| | Permitted value | 8.2 – 9.3 | 6.3 – 4.3 | 8.2 – 9.3 | 6.3 – 4.3 | 10.3 – 11.3 | 5.5 – 4.1 |
| Minimum power (0%) | Nominal value | 8.8 | 5.2 | 8.8 | 5.2 | 10.0 | 6.0 |
| | Permitted value | 8.2 – 9.3 | 6.3 – 4.3 | 8.2 – 9.3 | 6.3 – 4.3 | 9.5 – 10.5 | 6.8 – 5.2 |

(*) Automatically calculated from the PCB

Chimney Sweep Function enables boiler to generate maximum heating power.

After activation, boiler power % can be adjusted from minimum (0%) to maximum (100%) in DHW mode.

- A. Press and hold and at the same time for 6 seconds. When the function is enabled, displays shows "On" for few seconds followed by program row "303" alternating with % of boiler power.
- B. Press to gradually adjust power (increments of 1%).
- C. To exit press both buttons together for at least 6 seconds.

If value of CO₂-O₂ is different, check the electrodes and their relative distances. See Figure 11-1.

If necessary, replace electrodes and position them correctly.

If problem persists, use "**COMBUSTION ADJUSTMENT FUNCTION (CO₂%)**". See Section 11 General Maintenance, Figure 11-1 Electrodes. If problem persists, use **Section 9.8. Automatic Calibration Function, and Section 9.9 Manual Calibration Function.**

NOTICE

- Press to display instantaneous flow temperature for 15 seconds.
- Use a regularly calibrated combustion analyzer for combustion analysis.
- During normal operation boiler performs combustion control cycles. In this phase CO values higher than 400 ppm can occur for brief periods of time.

9.13 Combustion Adjustment Function (CO₂%)

This function sets out to partially adjust the value of CO₂%. Use the following procedure:

1. Press buttons and together for at least 6 seconds. When the function is enabled, displays shows "On" for a few seconds followed by program row "304" alternated with the % of boiler power;

2. After burner is lit, boiler reverts to maximum DHW power (100). When display shows "100" it is possible to partially adjust value of CO₂ %;
3. Press and . Display shows "00" alternating with function number "304" (flame flashes);
4. Press to raise or lower the amount of CO₂ (from -0.3% to +0.3%);
5. Press to save new value. Power value "100" will show on display again. Boiler continues operating at maximum DHW power.

This procedure can be used to adjust CO₂ to ignition power and minimum power by pressing after performing step 5 above.

6. After saving the new value (step 5 above), press to set boiler to ignition power. Wait for value of CO₂ to stabilize. Adjust as described in step 4 of procedure (power value is a number <> 100 and <> 0). Repeat step 5 to save.
7. Press to adjust boiler to **minimum power**. Wait for value of CO₂ to stabilize. Go to step 4 to adjust (power value = 00);
8. Exit function by pressing and together for at least 6 seconds, see step 1.

9.14 Check Firing Rate

1. Measure input, if a gas meter is installed in the system.
 - Turn off gas to all other appliances.
 - Activate some heating zones to dissipate heat.
 - Set boiler on high fire using Chimney Sweep Function.
 - Use ½, 1 or 2 cu ft dial on gas meter. Measure time required for two or more complete revolutions. Measure time for one or more minutes.
 - Calculate input.

9 - START UP PROCEDURE

For Natural Gas :

$$\text{Input (MBH)} = \frac{3600 \times \text{cu ft}}{\text{seconds}}$$

Example: Natural Gas - Gas flow from

Meter = 2 cu ft

Measured time = 72 seconds

$$= \frac{3600 \times 2 \text{ cu ft}}{72 \text{ seconds}} = 100 \text{ MBH}$$

For Propane (LP):

$$\text{Input (MBH)} = \frac{9160 \times \text{cu ft}}{\text{seconds}}$$

Input Rate (MBH)

For Metric formulas- See Glossary

- Compare measured input to table below. If calculated input is not in range given in Table below, check firing rate again after setting the combustion following steps in section 9.10.

Table 9-2 Input Rate @ High Fire (MBH)

| Approximate Rate @ 100% Fire (MBH) | |
|------------------------------------|-----|
| Size | |
| 125 | 125 |
| 150 | 150 |

9.15 Parameter Settings

Program boiler electronic board parameters as follows:

- Press **[MFR-]** and **[MFR+]** together, hold them down for 6 seconds until program "P01" appears on the display alternated with the set value;
- Press **[MFR-]** or **[MFR+]** to scroll the list of parameters;
- Press **[i/P]**, value of selected parameter begins flashing, press **[MFR-]** **[MFR+]** to change the value;
- Press **[i/P]** to confirm the value or press **[O/R]** to exit without saving.

Further information in regards to parameters listed in the following table are supplied together with required accessories if necessary.

| 9.16 Description Of Parameters: Factory Settings | | FACTORY SETTINGS | |
|--|---|------------------|-----|
| | | 125 | 150 |
| P01 | Manufacturer information | 01 | |
| P02 | Gas used 00 = Gas A (Natural Gas) 01 = Gas E (LPG Gas) | 00 | |
| P03 | Hydraulic system 00 = instantaneous appliance 03 = instantaneous appliance with pre-heat function 04 = heating only appliance with DHW thermostat 05 = appliance with external storage indirect tank 08 = heating only appliance 13 = instantaneous appliance with pre-heat function for solar application | 08 | 00 |
| P04 | Programmable relay 1 setting (optional): 00 = no function is associated 01 = close contact with a room thermostat request (other than ECR thermostat) 02 = close contact with a ECR room thermostat request 03 = relay for indicating low water pressure 04 = relay for error code display 05 = relay for kitchen fan function 07 = relay for post circulation pump 09 = DHW relay on with DHW program setting 10 = DHW relay on with DHW request; if P64 = 1 relay on with CH and DHW request 13 = relay for Cooling function 14 = close contact with room thermostat request (120V~) with post circulation 15 = close contact with open therm remote control request with post circulation | 02 | |
| P05 | Programmable relay 2 setting (optional): (Same configurations as Relay 1-P04) | 04 | |

parameters continued on
next page

9 - START UP PROCEDURE

| 9.16 Description Of Parameters: Factory Settings conti. | | FACTORY SETTINGS | | |
|---|---|-------------------|------|------|
| | | 125 | 150 | |
| P06 | Outdoor temperature sensor input configuration 00 = with outdoor temperature sensor connected, external temperature value has influence to calculate heating flow temperature set-point 01 = with outdoor temperature sensor connected, display shows external temperature value (no influence) 02...05 = no function is associated | 00 | | |
| P07 | 00..02 = No function is associated 03 = This is an input contact for CH request (e.g. trigger phone). When contact CN2 is closed and Room Thermostat (RT) requiring heat switches burner on. Note: verify heating mode is enabled (winter or heat only mode) 04 = This is an input contact for Low Temperature Thermostat (e.g. floor heating system). When Low Temperature Thermostat connected on CN2 cuts out, burner switches off and display shows E178 anomaly. Note: verify heating mode is enabled (winter or heat only mode) 05 = This is an input contact for external DHW recirculation pump. When contact CN2 is closed the pump runs for a specific period. To enable input it is necessary to set parameter P04 or P05 = 08 and P69 = 05 . Pump will run at P19 minutes (Summer/Winter mode or Only Winter mode) or P19/2 minutes (only Summer mode). | 00 | | |
| P09 | Manufacturer information | -- | | |
| P10 | Heating set-point setting OT / RT (Open Therm / Room Thermostat 120V~) 00 = with Remote Control (RC) connected, temperature request is RC set-point 01 = Temperature Request is highest set point between RC and PCB 02 = Temperature request is RU setpoint. The RT enable the gas boiler operates | 00 | | |
| P11..P12 | Manufacturer information | -- | | |
| P13 | Max. heating output (0-100%) | 100 | 80 | |
| P14 | DHW max. output (0-100%) | 100 | | |
| P15 | Min. heating output (0-100%) | 00 | | |
| P16 | Maximum CH set-point (°C) 00 = 176°F (80°C) 01 = 113°F (45°C) | 00 | | |
| P17 | Pump overrun time in heating mode (01-240 minutes) | 03 | | |
| P18 | Burner ignition delay in CH mode (00-10 minutes) - 00= 10 seconds | 03 | | |
| P19 | Manufacturer information | 07 | | |
| P20 | Pump overrun time in DHW mode (seconds) | 30 | | |
| P21 | Anti-legionellosis function 00 = Disabled - 01 = Enabled | 00 | | |
| P22 | Manufacturer information (set "22" to display parameters 42 and above) | 00 | | |
| P23 | Maximum DHW set-point temperature 113°-140°F (45°-60°C) , Default 49 = 120°F | 49 | | |
| P24 | Manufacturer information | 35 | | |
| P25 | No water safety device | 00 | | |
| P26..P31 | Manufacturer information | -- | | |
| P32..P41 | Diagnostics (See SERVICE Instructions) | -- | | |
| P44 | Temperature unit setting 00 = °C 01 = °F | 01 | | |
| P71* | Maximum Fan Speed | Setting | 115 | 220 |
| | | RPM | 6150 | 7200 |
| P72* | Minimum Fan Speed | Setting | 40 | 40 |
| | | RPM | 1150 | 1150 |
| To calculate fan speeds | | (P71 x 10) + 5000 | | |
| | | (P72 x 10) + 750 | | |

NOTE : To scroll to parameters **42 and above**, it is necessary to set **P22** to 22 before scrolling up to the parameter.

* See Tables : SECTION 12.2 - Parameters Setting For High Altitude.

9.17 Adjusting Maximum Heating Power

Maximum boiler heating power can be reduced to suit requirements of heating system it serves.

Table showing parameter **P13** values according to desired maximum power model is shown for each single boiler.

To access and edit **P13** values, proceed as described in Section 9.15 Parameter Settings.

Boiler Model - PARAMETER P13 (%) / Heating Output

| Btu/h | KW | DCB-125 | DCC-150 |
|---------|------|---------|---------|
| 20,400 | 6.0 | 0 | 0 |
| 23,800 | 7.0 | 4 | 3 |
| 27,200 | 8.0 | 7 | 6 |
| 30,700 | 9.0 | 11 | 9 |
| 34,100 | 10.0 | 15 | 12 |
| 40,900 | 12.0 | 22 | 18 |
| 47,700 | 14.0 | 30 | 24 |
| 54,500 | 16.0 | 37 | 29 |
| 61,400 | 18.0 | 44 | 35 |
| 68,200 | 20.0 | 52 | 41 |
| 75,100 | 22.0 | 59 | 47 |
| 81,900 | 24.0 | 67 | 53 |
| 88,700 | 26.0 | 74 | 59 |
| 95,500 | 28.0 | 80 | 65 |
| 102,300 | 30.0 | 88 | 71 |
| 109,200 | 32.0 | 96 | 75 |
| 112,600 | 33.0 | 100 | 80 |

FOR YOUR SAFETY READ BEFORE OPERATING

WARNING

If you do not follow these instructions exactly, a fire or explosion may result causing property damage, personal injury or loss of life.

- This appliance is equipped with an ignition device which automatically lights burner. **Do NOT try to light this burner by hand.**
- Before operating smell all around appliance area for gas. Be sure to smell next to floor because some gas is heavier than air and will settle to the floor.
- **Use only your hand to turn the gas shutoff valve.** Never use tools. If valve will not turn by hand, do not try to repair it, call a qualified service technician. Force or attempted repair may result in fire or explosion.
- **Do not use this appliance if any part has been under water.** Immediately call a qualified service technician to inspect appliance and to replace any part of control system and any gas control which has been under water.

CAUTION

WHAT TO DO IF YOU SMELL GAS

- Do not try to light any appliance.
- Do not touch any electrical switch; do not use any phone in your building.
- Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions.
- If you cannot reach your gas supplier, call the fire department.

10.1 Testing For Gas Leaks And Purging The Gas Supply

- With boiler gas service cock closed (spindle flats at right angles to valve). Pressure test gas supply and inlet pipe work connection to boiler gas service cock for soundness.
- Loosen screw of pressure inlet gas test port on gas valve. See section 13.4 Gas Valve. Verify gas supply is ON. Open boiler service cock to purge.
- Retighten test port screw and test for gas leaks. Close boiler gas shutoff device.

10.2 Boiler Operation

Domestic hot water supply always takes priority over central heating.

Demand for hot water required during central heating period, boiler automatically switches to hot water mode until demand is satisfied i.e. storage water is to required temperature.

This interruption in central heating is only when demand for hot water is present and should not be noticed by the User.

10.3 Central Heating Mode

1. With demand for heating, pump circulates water through the primary circuit.
2. Combustion fan comes on at ignition speed, closing the air pressure switch, allowing power to spark generator and gas valve, creating ignition in the combustion chamber.
3. Flame sensor acknowledges presence of flame in combustion chamber sending a signal to the control board.
4. After initial stabilization period the control board monitors supply and return temperatures and modulates fan speed and gas rate accordingly.
5. Once boiler satisfies CH call for heat, the unit will shutdown and enter 3 minute anti-cycling mode. The boiler pump will operate for 3 minutes to dissipate any residual heat.
If there is a subsequent CH call for heat, boiler will wait 3 minutes to operate.

10.4 Domestic Hot Water Mode

- When a tap is opened and water flow is sensed by DHW flow switch, domestic hot water call for heat is initiated.
- Water in the boiler is diverted from central heating system to domestic hot water heat exchanger to heat incoming domestic water.
- Combustion fan will come on at ignition speed, closing the air pressure switch, allowing power to flow to spark generator and gas valve, creating ignition in the combustion chamber.
- Flame sensor will acknowledge presence of flame in combustion chamber and send a signal to the control board.
- After initial stabilization period, the control board monitors supply and return temperatures and modulates fan speed and gas rate accordingly.
- Domestic call for heat ends when tap is closed and DHW flow switch does not see water flow.
- There is no anti-cycling mode after a DHW call for heat if there is demand.

10.5 Frost Protection

Boiler monitors supply and return water temperatures to enable frost protection which automatically turns boiler and pump on.

If water in boiler falls below 41°F (5°C), providing boiler is connected to power, boiler will operate until water temperature in the system reaches approximately 86°F (30°C).

Frost protection is for boiler only and not for complete Central Heating System.

10.6 Pump

If electricity is connected to the boiler, regardless if power is "On" or "Off" and has not operated for 24 hours for heating or hot water, boiler pump will operate automatically for one minute every 24 hours.

10.7 Low Water Pressure Sensor (Internal)

This device protects primary exchanger from damage. It will not allow boiler to run in a LOW water pressure situation. Low water condition occurs when water pressure drops below 7.0 psi (0.5 bar).

⚠ DANGER

Before servicing, turn off electrical power to boiler at service switch. Close manual gas valve to turn gas supply OFF to boiler. Failure to comply will result in death or serious injury.

⚠ CAUTION

Label all wires prior to disconnection when servicing controls. Wiring errors can cause improper and dangerous operation.

Note Verify proper operation after servicing.

Note Perform regular service and maintenance by qualified service agency at least once every 12 months to assure safe, trouble free operation and maximum efficiency.

Note A Heat Exchanger cleaning kit is available for annual service of the boiler. See repair parts manual for part number.

- Circulator pump and combustion air blower motor furnished with boiler are permanently lubricated from factory and require no further lubrication. Lubricate field sourced pumps and/or motors according to pump and/or motor manufacturer's instruction.
- Check following components are operating properly and are free of blockages or obstructions:
 - air vent;
 - check venturi air inlet for blockage and clean as required;
 - verify pressure test port cap and combustion test port caps are in place;
 - verify supply and return sensors are properly clipped to pipes as close to heat exchanger as possible;
 - Check boiler for any sign of leaks.
- Check external low water cutoff operation (if installed).
 - Check operation by pressing test button on low water cutoff.
 - "Low Water" LED on the external LWCO should illuminate and boiler should shut down.
 - Every 5 years remove low water cutoff. Reinstall after cleaning.
 - Every 10 years replace low water cutoff.
- Visual inspection of flame through sight glass. Burner should be fully illuminated.
- Check heating system expansion tank.

11.1 Beginning of Each Heating Season

- Check boiler area is free from combustible materials, gasoline, and other flammable vapors and corrosive liquids.
- Visually inspect combustion air and vent piping for proper operation. Check for and remove any obstruction to flow of combustion air or vent gases. Immediately repair or replace pipe showing deterioration or leakage. Reassemble per instructions in section 6. Ensure proper reassembly and resealing of system.
- Visually inspect condensate drain line for proper operation. Checking for deteriorated or plugged condensate drain line. Verify condensate trap drains freely and clean as required.
- Test safety relief valve for proper operation. Refer to valve manufacturer's instructions packaged with relief valve.
- Examine heat exchanger, burner, condensate lines, and clean (if necessary) by following instructions in section 11.3 - Component Replacement And Cleaning.

⚠ WARNING

Following service procedures must be performed by qualified service agent. Boiler owner shall not attempt these steps. Failure to do so could result in death or serious injury.

⚠ WARNING

Combustion chamber insulation in this product contains ceramic fiber material. Ceramic fibers can be converted to cristobalite in very high temperature applications. The International Agency for Research on Cancer (IARC) has concluded, Crystalline silica inhaled in the form of quartz or cristobalite from occupational sources is carcinogenic to humans (Group1). Avoid breathing dust and contact with skin and eyes. Use NIOSH certified dust respirator (N95). This type of respirator is based on the OSHA requirements for cristobalite at the time this document was written. Other types of respirators may be needed depending on the job site conditions. Current NIOSH recommendations can be found on the NIOSH website <http://www.cdc.gov/niosh/homepage.html>. NIOSH approved respirators, manufacturers, and phone numbers are also listed on this website. Wear long-sleeved, loose fitting clothing, gloves, and eye protection. Apply enough water to the combustion chamber lining to prevent dust. Wash potentially contaminated clothes separately from other clothing. Rinse clothes washer thoroughly. NIOSH stated First Aid. Eye: Irrigate immediately. Breathing: Fresh air.

⚠ WARNING

Before servicing, turn off electrical power to boiler at service switch. Close manual gas valve to turn gas supply OFF to boiler. Test for gas leaks on any gas carrying components after servicing. Service not complete until appliance operation verified per Installation, Operation & Maintenance Manual provided with boiler.

⚠ CAUTION

Label all wires prior to disconnection when servicing controls. Wiring errors can cause improper and dangerous operation. Failure to follow these instructions could result in minor or moderate injury.

NOTICE

Perform regular service and maintenance by qualified service agency at least once every 12 months to assure safe, trouble free operation and maximum efficiency.

11.2 Maintenance And Routine Servicing

Check and service boiler as necessary.

Frequency of servicing will depend upon installation conditions and usage, manufacturer recommends annually.

- Check flue terminal outside and ensure it is not blocked.
- Operate boiler. Check operation of boiler's controls.
- Ensure all system connections and fittings are sound. Correct any joints and fittings that maybe leaking.
- Follow safety valve manufacturer recommendations for service.

To ensure boiler operates at peak efficiency, following checks must be performed every year:

- check appearance and tightness of gas and combustion circuit gaskets
- check condition and position of ignition and flame sensing electrodes
- check condition of burner and its connection to aluminum front plate
- check for dirt in combustion chamber. Use vacuum cleaner for this cleaning operation
- check gas valve is calibrated correctly using combustion analyzer
- check there is no dirt in condensate trap
- check central heating system pressure
- check expansion tank pressure
- check vent system, clean if necessary

Record details and maintain service history.

11.3 Component Replacement And Cleaning

1. Remove any deposits from heat exchanger using suitable soft brush. *Do not* use brush with metallic bristles.
2. Check condition of the combustion chamber insulation panels. Any damaged panels must be replaced.
3. Check condition of burner and flame ports. Carefully clean with soft brush if necessary. Blockages may be removed with stiffer non-metallic brush. Do not use a brush with metallic bristles this might damage the burner.
4. Remove any fallen deposits from bottom of inner case.
5. Check condition of electrodes.
6. Check spark gap, positioning and height of electrodes.
7. Check fan impeller is clean and free to rotate.

⚠ DANGER

Before servicing, turn off electrical power to boiler at service switch. Close manual gas valve to turn gas supply OFF to boiler. Failure to comply will result in death or serious injury.


11.4 Draining the Boiler

- turn boiler off
- isolate electrical supply
- close boiler gas service cock
- allow boiler to cool
- drain boiler through onboard drain if available or external drain valve.

11.5 Draining the Heating Circuit

- Follow all steps in 11.4.
- Close central heating flow and return valves.
- Connect suitable pipe to drain point.
- Route it to suitable container.
- Open drain tap.

11-1 ELECTRODES



11.6 Hydraulic Unit (DHW)

For special areas, where water is harder than 200 ppm or 12 grains/ gallon, install polyphosphate dispenser or equivalent treatment system, compliant with current regulations.

11.7 Cleaning The Cold Water Filter

Boiler is fitted with cold water filter located on DHW hydraulic assembly (B). To clean:

- Drain domestic hot water system. (C - 150 only)
- Remove the flow sensor on top of assembly.
- Remove nut on DHW priority sensor unit using 18 mm wrench. (B)
- Pull out flow sensor and its filter.
- Soak in white vinegar and water mixture for 20 minutes.

NOTICE

When replacing and/or cleaning "O-rings" on hydraulic assembly (DHW), use only Molykote 111 as a lubricant, not oil or grease.


11.8 Final Commissioning

- Perform Automatic Calibration function as detailed in section 9.8.
- Allow heating system to heat. Balance the system to achieve temperature difference across heating supply and return pipes at the boiler.
- Check system for proper volume and pressure. See page 4 for acceptable volume and pressure.
- Turn off boiler.
- Thoroughly flush water pipe work.
- Repressurize the system.

11.9 Final Assembly

- Place front jacket in position over boiler. Secure in position at top using screws previously removed.
- If boiler is to be left in service with the User, set controls and room thermostat.
- If boiler is not to be handed over immediately, close boiler gas service valve and turn off electrical supply.
- If there is possibility of boiler being left during frost conditions drain boiler and system. See section 11: Component Replacement Or Periodic Cleaning. Manufacturer recommends attaching a label to the boiler drawing attention to the fact that the system has been drained.

Model DCCF-150



LEGEND

Hydraulic Assembly (Combi-150)

| | |
|----------|---------------------------|
| A | DHW exchanger screw |
| B | DHW priority sensor |
| C | Boiler/system drain tap |
| D | Controlled fast fill |
| E | DHW temperature NTC probe |
| F | Low Water Pressure Cutoff |
| G | DHW Cold inlet |
| H | DHW outlet |


11.10 User Information

Advise and demonstrated to User the following important information:

- A. How to light and turn off boiler. How to operate system controls.
- B. Importance of annual servicing of boiler to ensure safe and efficient operation.
- C. Servicing or replacement of parts shall be carried out by a qualified personnel.
- D. Ensure boiler controls and room thermostat, if fitted, are set to User's requirements.
- E. Tell User about sealed system pressure.
- F. Tell User if display is active and boiler has not operated for 24 hours for heating or hot water, the pump will automatically operate for 1 minute.
- G. Explain to User an internal frost thermostat is fitted in boiler, and electrical supply to boiler must be left on for frost protection to operate.
- H. Show User position of pressure relief valve discharge pipe.
- I. Leave this Installation, Operation and Maintenance Manual with User for use on future calls.

11.11 Safety Flue Thermostat - *DO NOT* disable this safety device.

Safety Flue Thermostat found on the flue inside the boiler, interrupts flow of gas to the burner if the temperature overheats.

After verifying the cause of the trip, press  for about 2 seconds.

11.12 Flue Pressure Switch (125-150 Only)

DO NOT disable this safety device.

This device, positioned inside the sealed chamber, interrupts flow of gas to the burner if flue pressure exceeds 1.6 in w.c. (4 mbar). Verify if vent is blocked before resetting the boiler.

NOTICE

When servicing the appliance, check the condition and position of flame sensing electrode and replace it if necessary.

11.13 Replacement Parts


Perform Automatic Calibration procedure described in section 9.8 if one or more of the following components are replaced. Check and adjust CO₂% value as indicated in the Combustion Table.

Components replaced:

- Primary heat exchanger
- Fan
- Gas valve
- Gas orifice
- Burner
- Flame sensing electrode
- Spark electrode

12 TECHNICAL DATA

12.1 Ratings and Capacity

|  | | | | | |
|---|------------------------------|---------|--|--|----------------------|
| Model Number | CH Input, MBH ⁽¹⁾ | | ⁽¹⁾⁽²⁾ CH Heating Capacity, MBH * | ⁽¹⁾⁽³⁾ Net AHRI Rating Water, MBH | ⁽²⁾ AFUE% |
| | Maximum | Minimum | | | |
| DCBF-125 | 125 | 22 | 113 | 98 | 95.0 |
| DCCF-150 | 125 | 22 | 113 | 98 | 95.0 |
| <p>(1) 1000 Btu/hr (British Thermal Units Per Hour)</p> <p>(2) Heating Capacity and AFUE (Annual Fuel Utilization Efficiency) are based on DOE (Department of Energy) test procedures.</p> <p>(3) Net AHRI Ratings based on piping and pickup allowance of 1.15. Contact Technical Support before selecting boiler for installations having unusual piping and pickup requirements, such as intermittent system operation, extensive piping systems, etc.</p> | | | | | |

*Max CH Supply temp 176° F (80°C)

12.2 Domestic Hot Water Specifications

| | | |
|----------------------------------|---------------------------------------|-----|
| Item | DCCF-150 | |
| Input Ratings (MBH) | Min | 22 |
| | Max | 153 |
| Output Ratings (MBH) | Min | 19 |
| | Max | 136 |
| Domestic Water Pressure | 2.9 psi (0.2 bar) - 116 psi (8.0 bar) | |
| Minimum Flow Rate | 0.50 GPM | |
| Maximum Flow Rate | 3.50 gpm | |
| Flow Rate 77°F (43°C) Temp. Rise | 3.25 gpm | |
| DHW Supply Connection Size | 1/2" Sweat | |
| Cold Water Input Connection Size | 1/2" Sweat | |

*Max DHW temp 140° F (60° C)

12.3 High Altitude Ratings and Capacity

For elevations between 2000 ft (600 m) and 10,000 ft (3048 m), use the following information:

| Altitude | Model Number | Input, MBH (KW) | | Heating Capacity, MBH* | AFUE, % | Domestic Hot Water (DHW) Circuit** | | | |
|-----------------------------|--------------|-----------------|---------|------------------------|---------|------------------------------------|----------------|-----------------|-----------------|
| | | Maximum | Minimum | | | Max Input, MBH | Min Input, MBH | Max Output, MBH | Min Output, MBH |
| 2,000-4,500 ft (600m-1350m) | DCBF-125 | 113 | 22 | 101 | 95.0 | | | | |
| | DCCF-150 | 113 | 22 | 101 | 95.0 | 137 | 22 | 122 | 19 |

* Max CH Supply temp 176° F (80° C) for DCBF-125 and DCCF-150
 * Max DHW temp 140° F (60° C)
 **DCCF-150 Max DHW Flow rate 3.5 gpm (13.2 l/min)

12.4 High Altitude Chart

| | GAS | | Natural | | LP | |
|--------------------------------------|-------|-------------|-----------------------|--------------------------------|-----------------------|--------------------------------|
| | Model | | Altitude | | | |
| | | | 0-2,000 ft. [0-610 m] | 2,000- 10,000 ft [610-3,048 m] | 0-2,000 ft. [0-610 m] | 2,000- 10,000 ft [610-3,048 m] |
| Parameter P71 High Fire Fan Speed | 125 | Setting RPM | 115 6150 | 60 5600 | 65 5650 | 40 5400 |
| | 150 | Setting RPM | 220 7200 | 170 6700 | 170 6700 | 150 6500 |
| Parameter P72 Low Fire Fan Speed | 125 | Setting RPM | 40 1150 | | 25 1000 | |
| | 150 | Setting RPM | 40 1150 | | 25 1000 | |

CO Limit < 200 ppm

13 - TROUBLE SHOOTING

13.1 Error Messages And Resetting The Boiler

| E | Error Description | Operation |
|-----------------|---|--|
| 09 | Gas valve connection fault | Check cable PCB/gas valve and gas valve plug |
| 10 | Outdoor sensor fault | Check sensor and cable |
| 15 | Gas valve command fault | Verify all cables. Replace PCB. Call authorized SERVICE center |
| 20 | Central Heating NTC sensor fault | Check sensor and cable |
| 28 | Flue NTC heat exchanger sensor fault | Check sensor and cable |
| 40 | Return NTC sensor fault | Check sensor and cable |
| 50 | Domestic Hot Water NTC sensor fault | Check sensor and cable |
| 53 | Obstruction in flue pipe, Recirculation, Out of Calibration, Poor gas quality | Check for obstruction in flue pipe. Check gas pressure, check gas orifice. Check for recirculation, recalibrate, check gas quality. |
| 55 | PCB not programmed | Call authorized SERVICE center |
| E72/E92 | R | Combustion test alarm during commissioning / calibration |
| | | Check flame sensor, check for obstruction in flue pipe, check for recirculation, check gas pressure, check gas orifice, check gas quality. Perform Calibration Function. |
| E83 | OT Communication Failure | Check OT connection, remove power, reconnect OT connections, if problem persists replace service key. |
| 84-86-87 | Communication problem between boiler board and control unit | Probable short circuit on wiring. Check cable between control unit and boiler |
| 109 | Pre-circulation alarm (temporary fault) | Check correct circulation of water and pump. Check supply and return wiring is correct. |
| 110 | R | Safety thermostat tripped due to over temperature (pump probably blocked or air in heating circuit) |
| | | Check safety thermostat and cable; check correct circulation of water and pump |
| 118 | Hydraulic pressure too low. | Refill heating system by opening cold water tap |
| 117 | Hydraulic pressure too high. | Relieve pressure via relief valve or drain. Ensure water feed is operating correctly. |
| 125 | R | No circulation of water (control performed via temperature sensor). |
| | | Check correct circulation of water and pump. Check correct connection of NTC sensor on pipe |
| 128 | R | Loss of flame |
| | | Check sensing electrode and cable, flue recirculation, electrical continuity between burner and ground, gas pressure, gas orifice. Enable automatic calibration. Call authorized SERVICE center. |
| 130 | R | NTC flue sensor tripped due to over temperature |
| | | Check thermostat, correct circulation of water and pump. Check status of primary exchanger. |
| 131 | R | Thermo fuse tripped due to over temperature or wire harness disconnected from thermo fuse, off the board, or wire harness may be cut. |
| | | Check thermo fuse, correct circulation of water and pump. Check status of primary exchanger. Replace heat exchanger. Call authorized SERVICE center. Verify wire harness installation and continuity. |
| 133 | R | Ignition failure |
| | | Check correct operation of condensate trap. Check sensing electrode, spark electrode and cable. Check flue recirculation, electrical continuity between burner and ground. Check gas orifice and gas pressure. Enable automatic calibration function. Call authorized SERVICE center |
| 134 | R | Gas supply valve blocked |
| | | Check gas pressure, sensing electrode, spark electrode and cable, replace PCB if it necessary. Call authorized SERVICE center |
| 135 | Internal error | Verify all cables. Replace PCB. Call authorized SERVICE center |
| 160 | Fan fault | Check fan and cable |
| 162/317 | Incorrect power supply frequency. | Incorrect power supply frequency. |

13 - TROUBLE SHOOTING

13.1 Error Messages and Resetting the Boiler - continued

| E | Error Description | Operation |
|----------------|--|--|
| 169 | Flue pressure switch (contact open) | Check pressure switch and cable. Check obstruction on flue pipe |
| 164/384 | R | Fault flame (parasitic flame). |
| | | Check correct operation of T. gas valve. |
| 165/385 | Input voltage too low. | Check power supply |
| E178 | Low return water temperature / anti-freeze function active | Check the return water sensor, check the circulator, check the correct circulation of the water. Boiler will exit status when condition is resolved. |

To RESET **R** boiler press  button for at least 2 seconds.

For other error codes not described in table please contact manufacturer at 1(800) 325-5479.

| Anomalies Only Displayed in the Fault History | | |
|---|---|---|
| E62 | Anti-wind activation with increase of the minimum fan speed | Check the position of the terminal of the flue duct. |
| E63/E65 | Combustion level out of range | Check flue recirculation and combustion levels. |
| E65 | Maximum value of the speed reached / correction of the flame signal | Check flue recirculation on the flue duct. |
| E67 | Anti-wind activation at maximum power | Check the position of the terminal of the flue duct. |
| E69 | Combustion level out of range | Check flue recirculation and the combustion levels. |
| E70 | Flame signal problem/micro interruption of the flame signal | Check cable and integrity of the sensing electrode, verify the continuity between burner and earth. |
| E73 | Combustion adjustment / modified during operation | Review and monitor other codes such as E53 and E92 |

13 - TROUBLE SHOOTING

13.2 Anomalies Table for the Installer - Use this table to report the anomaly values.

SYSTEM STATUS CODES
 0 STANDBY
 1 DHW "ON"
 2 CHIMNEY SWEEP ACTIVE
 3 CH "ON"
 4 PREHEAT "ON"
 5 CH NO FROST "ON"
 6 DHW NO FROST "ON"
 8 THERMOSTATIC POST- CIRCULATION

FAILURE CODE

NUMBER OF TIMES OCCURRED

TEMPERATURE

| | | Anomaly Number | Anomaly Code | Consecutive Counter for the Same Anomaly | Number of Days Elapsed From the Anomaly Event | System Status | Phase Status | CH Flow Temperature Value During the Anomaly vent |
|------------------|-----|----------------|--------------|--|---|---------------|--------------|---|
| NO RESET ANOMALY | P32 | C00 | | | | | | |
| | P33 | C01 | | | | | | |
| | P34 | C02 | | | | | | |
| | P35 | C03 | | | | | | |
| | P36 | C04 | | | | | | |
| | P37 | C05 | | | | | | |
| RESET ANOMALY | P38 | C06 | | | | | | |
| | P39 | C07 | | | | | | |
| | P40 | C08 | | | | | | |
| | P41 | C09 | | | | | | |

C00: LAST FAILURE
 C06: FIRST FAILURE
 C07: LAST LOCKOUT
 C09: FIRST LOCKOUT

PHASE STATUS CODES
 0: STANDBY
 1: PREPURGE
 3: INTERPURGE
 4: SAFETY TIME
 5: RUNNING
 6: LOCKOUT
 11: INTERURGE
 15: POST VENTILATION
 16: THERMOSTATIC POST VENTILATION

- **APPLIANCE** - Device to convert gas into energy; term includes any component, control, wiring, piping or tubing required to be part of the device.
- **ANSI** - American National Standards Institute, Inc. oversees the creation and maintenance of voluntary consensus standards, including ANSI Z21.13/CSA 4.9: Gas-Fired Low Pressure Steam and Hot Water Boilers.
- **ASME - Association of Mechanical Engineers**
Establishes rules of safety governing the design, fabrication, and inspection of boilers and pressure vessels, determining the MAWP of such vessels.
- **ASTM** - American Society for Testing and Materials. ASTM International is one of the largest voluntary standards development organizations in the world, a trusted source for technical standards for materials, products, systems, and services. Known for their high technical quality and market relevancy, ASTM International standards have an important role in information infrastructure that guides design, manufacturing and trade in the global economy.
- **AUTHORITY HAVING JURISDICTION** - Individual or organization adopting and enforcing codes, rules, and by-laws governing various concerns of a community. Commonly referred to as "final authority" for any matters relating to LIFE SAFETY and BUILDING CONSTRUCTION within a community.
- **BOILER** - Appliance intended to supply hot liquid for space-heating, processing or power purposes.
- **BTU** - Abbreviation for British Thermal Unit. Quantity of heat required to raise the temperature of 1 pound of water 1°F.
- **BURNER** - Device for the final conveyance of gas or mixture of gas and air, to the combustion zone.
- **CALIBRATE** - Make fine adjustments or divide into marked intervals for optimal measuring.
- **COAXIAL VENTING** - Sharing the same center.
- **COMBUSTION** - Rapid oxidation of fuel gases accompanied by the production of heat or heat and light. Complete combustion of fuel is possible only in the presence of an adequate supply of Oxygen.
- **COMBUSTIBLE MATERIAL** - Materials made of or surfaced with wood, compressed paper, plant fibers, or other materials capable of being ignited and burned. Such material shall be considered combustible even though flame-proofed, fire-retardant treated, or plastered.
- **COMBUSTION AIR** - Air that is drawn into an appliance to mix with fuel and support combustion.
- **CONDENSATE** - Liquid separated from flue gas due to a reduction in temperature.
- **DIRECT VENT BOILER** - Boiler constructed and installed so that all combustion air is derived directly from outdoors and all vent gases are discharged to outdoors.
- **DOMESTIC** - Relating to household usage as opposed to commercial usage.
- **DOMESTIC WATER** - Potable drinking water - tap water.
- **DRAFT** - Pressure difference causes gases or air to flow through a chimney, vent, flue or appliance.
- **FLA** - Full load amps.
- **FLUE** - Enclosed passageway for conveying combustion gases.
- **FLUE GASES** - Products of combustion plus excess air in appliance flues or heat exchangers.
- **GAS SUPPLIER** - Party that sells the commodity of Natural Gas (Gas A) or LPG (Gas E).
- **HIGH-VOLTAGE** - Circuit involving a potential of not more than 600 volts and having circuit characteristics in excess of those of a low-voltage circuit.
- **HYSTERESIS (DIFFERENTIAL)** - Difference between the temperature at which the thermostat switches off - and the temperature at which it switches on again.
- **IGNITER** - Device utilizing electrical energy to ignite gas at the main burner.
- **LEAK CHECK** - Operation performed on a gas piping system to verify the system does not leak.
- **LICENSED QUALIFIED INSTALLER / SERVICE TECHNICIAN** - Any individual, firm, corporation or company that either directly or through a representative is engaged in the installation, replacement, repair or servicing of gas piping, venting systems, appliances, components, accessories, or equipment, and whose representative is experienced and trained in such work and has complied with the requirements of the authority having jurisdiction.
- **LOW WATER CUTOFF** - Device constructed to automatically cut off fuel supply when the surface of water in the boiler falls to the lowest safe water level.
- **LOW-VOLTAGE** - Circuit involving a potential of not more than 30 volts.

- **METRIC GAS METERS**

- **Natural Gas**

$$\text{MBH} = \frac{127,116 \times \text{cu meters}}{\text{Seconds}}$$

For example: Gas Meter measures 0.1 cubic Meters in 100 seconds

$$\text{MBH} = \frac{127,116 \times 0.1}{100} = 127 \text{ MBH}$$

- **Propane Gas (LP)**

$$\text{MBH} = \frac{383,482 \times \text{cu meters}}{\text{Seconds}}$$

- **NATIONAL BOARD OF BOILER AND PRESSURE VESSEL**

INSPECTORS - Group composed of boiler and pressure vessel inspectors representing states, cities and provinces enforcing pressure equipment laws and regulations.

- **PRESSURE TEST** - Operation performed to verify gas tight integrity of gas piping following its installation or modification.
- **PURGE** - To free gas conduit of air or gas, or mixture of gas and air.
- **PURGE TIME** - Period of time intended to allow for dissipation of any unburned gas or residual products of combustion.
- **QUALIFIED AGENCY** - Any individual, firm, corporation, or company engaged in and responsible for:
 - Installation, testing, or replacement of gas piping, or connection, installation, testing, repair or servicing of appliances and equipment.
 - Experienced in such work.
 - Familiar with all precautions required.
 - Complies with all requirements of authority having jurisdiction.
- **SAFETY RELIEF VALVE** - Valve designed to relieve pressure in hot water supply system when pressure exceeds pressure capability of equipment.
- **SAFETY SHUTOFF DEVICE** - Device that will shut off gas supply to controlled burner in event source of ignition fails.
- **SEDIMENT TRAP** - Gas piping arrangement designed to collect any liquid or solid contaminant before reaching gas valve.
- **SERVICE** -Supply, installation, or maintenance of goods carried out by a Qualified Installer / Service Technician.


- **TWO PIPE SYSTEM** - Type of venting that allows for exhaust flue and intake air piping to be separated from each other. Fresh air may be drawn in at a different area from where flue terminal is located.
- **VENT** - Passageway used to convey flue gases from appliance vent connector to outdoors.
- **VENTING SYSTEM** - Continuous open passageway from of appliance vent connector to outdoors for purpose of removing flue or vent gases.

A-1 MODELS 125 - Heat Only

240011359 REV C 125

LEGEND - LEGENDE:

- 1-FUSES 3, 15 A - Fusibles 3, 15 A
- 2-Supply 120V - 60Hz - Alimentation
- 3-Fan - Ventilator
- 4-Air pressure switch - Pressostat différentiel fumées
- 5-Safety Thermostat - Thermostat de Sécurité
- 6-Gas Valve - Vanne a gaz
- 7-Exchanger sensor - Sonde échangeur
- 8-Water Pressure Switch - Pressostat Eau
- 9-NTC return Sensor - Sonde NTC retour
- 10-NTC flow sensor - Sonde NTC départ
- 11-Flue Safety Thermostat - Thermostat Fumées
- 12-Remote User Interface or Open Therm
- 13-Prev. for OutsideSensor - Pred. Sonde Extérieure
- 14-Link 24V - Joint 24V
- 15-DHW Indirect sensor or T-Stat
- 16-Flame Sensing Electrode - Electrode présence veilleuse
- 17-Ignition Electrode - Electrode d'allumage
- 18-Three Way Valve - Soupape Trois Voies
- 19-Pump - Pompe
- M1-Main Power Terminal Board - Bornier d'alimentation
- M2-Accessories Terminal Board - Bornier pour accessoires



WIRING DIAGRAM


If any of the original wire as supplied with the appliance must be replaced, it must be replaced with wire having same specifications.

SCHEMA DE CABLAGE
Si un câble d'origine, tel qu'il est fourni avec l'appareil, doit être changé, il doit être remplacé par un câble qui possède les mêmes caractéristiques.

- BI = Blue - Bleu
- Br = Brown - Brun
- Bk = Black - Noir
- R = Red - Rouge
- W = White - Blanc
- G = Green - Vert
- Gr = Grey - Gris
- IB = Light Blue - Celeste

* See wiring section of application guide for more details

A-2 MODELS 150 - Combi



INSTALLATION AND CHECK-OUT CERTIFICATE

Boiler Model _____ **Serial #** _____ **Date Installed** _____

Measured BTU/HR input _____

- Installation instructions have been followed**
- Checkout procedure and adjustments performed**
- Maintenance and Service issues reviewed with owner/ maintenance person**
- Installation booklet affixed on or adjacent to boiler**

Installer (Company) _____

Address _____

Phone _____

Installer's Name _____

Signature _____

IMPORTANT

In accordance with Section 325 (f) (3) of the Energy Policy and Conservation Act, this boiler is equipped with a feature that saves energy by reducing the boiler water temperature as the heating load decreases.

This feature is equipped with an override which is provided primarily to permit the use of an external energy management system that serves the same function.

THIS OVERRIDE MUST NOT BE USED UNLESS AT LEAST ONE OF THE FOLLOWING CONDITIONS IS TRUE:

- An external energy management system is installed that reduces the boiler water temperature as the heating load decreases.
- This boiler is not used for any space heating
- This boiler is part of a modular or multiple boiler system having a total input of 300,000 BTU/hr or greater.
- This boiler is equipped with a tankless coil.



ECR international

2201 Dwyer Avenue, Utica, NY 13501

Tel. 800 253 7900

www.ecrinternational.com

All specifications subject to change without notice.

©2019 ECR International, Inc.

APPLICATION GUIDE FOR USE WITH

FLOOR STANDING HEATING ONLY - 125F

&

FLOOR STANDING COMBI - 150F

This manual has been prepared for use with the appropriate Installation, Operation and Maintenance Manual.



Manufactured by:
ECR International Inc.
2201 Dwyer Avenue, Utica, NY 13501
Tel. 800 253 7900
www.ecrinternational.com
PN 240012560 REV. A [05/15/2019]

TABLE OF CONTENTS

| | |
|---|----|
| Important Safety Information | 3 |
| Labor Saving Piping Manifolds / Near Boiler Piping Connections | 4 |
| General Information - Hydronic Piping | 6 |
| General Information - Wiring | 8 |
| Piping and Wiring Diagrams | |
| Piping Legend..... | 9 |
| 125F Zone Circulator Pumps - Piping Diagram..... | 10 |
| 125F W/ Indirect Zone Pumps, DHW Tank, Tank Sensor - Wiring Diagram..... | 11 |
| 125F W/ Indirect Zone Pumps & DHW Tank, Tank T-Stat - Wiring Diagram | 12 |
| 125F With Zone Valves - Piping Diagram | 13 |
| 125F With Zone Valves, DHW Tank, Tank Sensor - Wiring Diagram..... | 14 |
| 125F Indirect Zone Valves, DHW Tank W/ Tank T-Stat - Wiring Diagram | 15 |
| 150F With Zone Circulator Pumps - Piping Diagram..... | 16 |
| 150F With Zone Pumps - Wiring Diagram | 17 |
| 150F With Zone Valves - Piping Diagram | 18 |
| 150F With Zone Valves - Wiring Diagram..... | 19 |
| Low Mass Piping and Wiring | |
| Low Mass - Piping Diagram | 20 |
| Low Mass - Wiring Diagram..... | 21 |
| Optional Equipment & Accessories | |
| Outdoor Temperature Sensor..... | 22 |
| Indirect Storage Tank Sensor & Thermostat..... | 24 |
| Wiring Diagrams | |
| 125F - Heat Only Wiring Diagram..... | 25 |
| 150F - Combi Wiring Diagram..... | 26 |
| Altitude Effects On Boiler Performance | 27 |
| Application Table - Indirect Tank Sizing | 28 |
| Low Water Cutoff Application | 29 |
| Error Code Table | 31 |
| Troubleshooting Chart | 32 |
| Fault Solution Sections | 34 |

IMPORTANT SAFETY INFORMATION

1. General

Boiler installation shall be completed by qualified agency. See Installation, Operation & Maintenance Manual for additional information.

WARNING

Fire, explosion, asphyxiation and electrical shock hazard. Improper installation could result in death or serious injury. Read this manual and understand all requirements before beginning installation.

2. Become familiar with symbols identifying potential hazards.



This is the safety alert symbol. Symbol alerts you to potential personal injury hazards. Obey all safety messages following this symbol to avoid possible injury or death.

DANGER

Indicates a hazardous situation which, if not avoided, WILL result in death or serious injury.

WARNING

Indicates a hazardous situation which, if not avoided, could result in death or serious injury.

CAUTION

Indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.

3. Installation shall conform to requirements of authority having jurisdiction or in absence of such requirements:

- *United States*
 - National Fuel Gas Code, ANSI Z223.1/NFPA 54.
 - National Electrical Code, NFPA 70.
- *Canada*
 - Natural Gas and Propane Installation Code, CAN/CSA B149.1.
 - Canadian Electrical Code, Part I, Safety Standard for Electrical Installations, CSA C22.1

4. Where required by authority having jurisdiction, installation shall conform to Standard for Controls and Safety Devices for Automatically Fired Boilers, ANSI/ASME CSD-1.

Additional manual reset low water cutoff or high limit may be required.


5. Requirements for Commonwealth of Massachusetts:

Boiler installation must conform to Commonwealth of Massachusetts code 248 CMR which includes but is not limited to:


- Installation by licensed plumber or gas fitter.

NEAR BOILER PIPING CONNECTIONS

MAHF-125 HEATING ONLY WITH OPTIONAL INDIRECT DHW CONNECTION




MAHF-125 HEATING ONLY WITHOUT OPTIONAL INDIRECT DHW CONNECTION



| LEGEND | | 125 |
|--------|---|-----------|
| A | Heating supply connection | 1¼" sweat |
| B | Drain Connection for condensate | ¾" NPT |
| C | Gas shutoff connection | ¾" NPT |
| D | Optional Indirect DHW connection (may exit right or left) | ¾" sweat |
| E | Heating return connection | 1¼" sweat |

MACF-150 COMBI



| LEGEND | | 150 |
|--------|---------------------------------|-----------|
| A | Heating supply connection | 1¼" sweat |
| B | DHW outlet | ½" sweat |
| C | Drain connection for condensate | ¾" NPT |
| D | Gas shutoff connection | ¾" NPT |
| E | Cold DHW inlet tap | ½" sweat |
| F | Heating return connection | 1¼" sweat |

⚠ WARNING

Burn and scald hazard! Manufacturer requires installation of field supplied anti-scald valve. Failure to follow these instructions could result in death or serious injury.

General Information:

Piping installation, materials, and joining methods shall conform to requirements of authority having jurisdiction or in absence of such requirements:

- **USA** - National Fuel Gas Code, ANSI Z223.1/NFPA 54
- **Canada** - Natural Gas and Propane Installation Code, CAN/CSA B149.1

Manufacturer Requirements/Recommendations:

- Manufacturer requires all domestic hot water (DHW) installations use an anti-scald valve. Local codes may require additional equipment (expansion tank, relief valves, etc.) Select and size equipment to suit installation and meet code requirements.
- Use of a water filter on incoming water supply line.
- Manufacturer recommends use of a magnetic dirt separator in the hydronic system where there are cast iron or steel components, or where the previous boiler was a cast iron heat exchanger. The abrasive, extremely fine sediment is difficult to remove and can deposit onto heat exchanger surfaces and accumulate in pump cavities causing reduced efficiency and premature wear.
- The ASME temperature and pressure relief valve and temperature and pressure gauge shall be installed to conform to requirements of the authority having jurisdiction. Refer to appropriate manufacturer instructions for installation requirements.
- If piping manifold is not used, a primary/secondary piping arrangement is manufacturer required. Maximum of 12" separation between supply and return pipe (closely spaced tees) of the boiler shall be maintained.
- Limit combined supply and return pipe lengths to maximum linear lengths of 20 ft (6.1 m) between boiler and closely spaced tees, when minimum 3/4" NPT pipe size is used. Linear length may be increased if supply and return pipe size is increased to limit pressure drop.
- Manufacturer recommends installing a shutoff and purge valve to use during commissioning to ensure the boiler does not shut down due to over temperature. Do not install shutoff between boiler and LWCO.

FOR YOUR SAFETY READ BEFORE OPERATING

⚠ DANGER



Hot Water Can Scald!

Water heated to temperature for clothes washing, dish washing and other sanitizing needs can scald and cause permanent injury. Children, elderly, and infirm or physically handicapped persons are more likely to be permanently injured by hot water. Never leave them unattended in bathtub or shower. Never allow small children to use a hot water tap or draw their own bath.

If anyone using hot water in the building fits the above description, or if state laws or local codes require certain water temperatures at hot water taps, you must take special precautions:

- Use lowest possible temperature setting.
- Install some type of tempering device, such as an automatic mixing valve, at hot water tap or water heater. Automatic mixing valve must be selected and installed according to manufacturer's recommendations and instructions.
- Water passing out of drain valves may be extremely hot. To avoid injury:
 - Make sure all connections are tight.
 - Direct water flow away from any person.

GENERAL INFORMATION - HYDRONIC PIPING

| Water Temperature Setting | 1st Degree Burn Exposure Time For An Adult | 2nd and 3rd Degree Burn Exposure Time For An Adult |
|---------------------------|--|--|
| 120° F | 1 minute | 5 minutes |
| 130° F | 5 seconds | 30 seconds |
| 140° F | 2 seconds | 5 seconds |
| 150° F | 1 second | 1.5 seconds |
| 160° F | Instantaneous | 0.5 seconds |

Note: Warning for Infants, Children, and Elderly: Great care must be taken when exposing the aforementioned groups to warm or hot water as they can be badly burned in exposure times less than half of the time for an adult.

Note

Provided Wiring and Piping illustrations are meant to show system concepts only. Installer is responsible for all equipment required by authority having jurisdiction.

Note

Arrange piping to prevent water dripping onto boiler.

All piping diagrams are shown with optional DHW Indirect Tank where applicable.

Use of Indirect Storage Tank (DHW):

Note

Sensors supplied with this boiler are proprietary to the manufacturer. Use of alternate sensors *WILL* diminish boiler performance.

- Use either DHW sensor or Indirect Tank Thermostat to interface with boiler. Wire to M2 terminals #9 and #10.
- Use of booster pump to increase flow rate to indirect tank is not recommended by manufacturer.
- Locate tank as close to boiler as possible.
- Size DHW tank, piping, and system to use only internal boiler pump.
- See available pump/flow rate chart, page 35 of this manual.
- Change P03 on boiler for application as specified on the wire diagram and Boiler Control section of Installation, Operation & Maintenance Manual supplied with the boiler.

GENERAL INFORMATION - WIRING

Electrical Wiring Information:

All field wiring shall conform to the authority having jurisdiction or, in the absence of such requirements to:


- **USA:** National Electrical Code, ANSI/NFPA 70,
- **Canada:** Canadian Electrical Code, Part I, CSA C22.1: Safety Standard for Electrical Installations.

Wiring diagrams shown in this manual utilize the ARGO™ Universal Control, the optional use of an Indirect Domestic Hot Water Tank, and optional use of a H2O Buffer Tank.

Reference the zone control manufacturer instruction manual for control operation and priority setting of DHW zones.

Note → **DO NOT** use 120 V thermostat terminals (m1- #1 and #2).

Note → Provided Wiring and Piping illustrations are meant to show system concepts only. Installer is responsible for all equipment required by authority having jurisdiction.



PIPING LEGEND

PIPING LEGEND



ZONE VALVE



BALL VALVE




AIR SEPARATOR



CIRCULATOR



DRAIN



COMBINATION FILL



FLOW CHECK VALVE



BYPASS VALVE




DIVERTER VALVE




T&P OR RELIEF VALVE



THERMOSTATIC MIXING VALVE



PURGE VALVE



INDIRECT DHW TANK



INDIRECT TANK AQUASTAT



10K Ω INDIRECT DHW TANK SENSOR



TEMPERATURE & PRESSURE GAUGE




EXPANSION TANK



FLAT PLATE HEAT EXCHANGER
(COMBI ONLY)




STRAINER




MAGNETIC DIRT SEPARATOR

125F WITH ZONE CIRCULATOR PUMPS




125F WITH INDIRECT ZONE PUMPS & DHW TANK W/ TANK SENSOR



If adding an indirect tank with sensor to a Heating **Only Boiler**, change P03 from 08 to 05. See Section 9, Parameter Settings in Boiler Installation, Operation & Maintenance Manual for details.


125F W/ INDIRECT ZONE PUMPS & DHW TANK W/TANK T-STAT - WIRING DIAGRAM




Reference zone control manufacturer instructions for details on setting priority if necessary.

If adding an indirect tank with **Thermostat** to a **Heating Only Boiler**, change P03 from 08 to 04. See Section 9, Parameter Settings in Boiler Installation, Operation & Maintenance Manual for details.


125F WITH ZONE VALVES - PIPING DIAGRAM



125F WITH ZONE VALVES, DHW TANK & TANK SENSOR




125F INDIRECT ZONE VALVES, DHW TANK ,& TANK T-STAT




If adding an indirect tank with **Thermostat** to a **Heating Only Boiler**, change P03 from 08 to 04. See Section 9, Parameter Settings in Boiler Installation, Operation & Maintenance Manual for details.

150F WITH ZONE CIRCULATOR PUMPS




150F WITH ZONE PUMPS




150F WITH ZONE VALVES - PIPING DIAGRAM

150F WITH ZONE VALVES



150F WITH ZONE VALVES




Low Mass Piping

When installing low mass systems, additional water mass may be required to avoid short cycling by the boiler. In these applications it is recommended that a buffer tank be installed.

Buffer Tank on Central Heat Circuit

Note:

- DHW piping not shown for clarity. Reference applicable sections of this manual for DHW piping details.
- Internal Boiler circulator used on Primary circuit.
- Reference Buffer Tank Installation Manual for proper sizing and installation.



Low Mass Boiler Wiring with Buffer Tank

Connect the buffer tank aquastat to terminals 6 and 7 on terminal block M2.

System wiring remains as shown in the previous wiring diagrams.



OPTIONAL EQUIPMENT

Optional Equipment

IMPORTANT: Sensors supplied with this boiler are proprietary to the manufacturer. Use of alternate market sensors *WILL* diminish boiler performance.

1. **1k Ω** Outdoor Air Sensor, if used.
 - A. Boiler automatically recognizes sensor when used.
 - B. See Chart 1 for sensor data. Sensor part number BD710487302V
 - C. Locate outdoor sensor to protect against wind and direct sunlight. Mounting instructions provided with sensor.
 - D. Maximum wire length is 100 ft (30m) for 22 ga. wire, or 150F ft (45m) for 18 ga. wire.
 - E. Connect wires to M2 OUTDOOR SENSOR terminals 4 & 5. Wires are interchangeable. See Accessories.

2. **10k Ω** Sensor for Indirect DHW Tank (Heating Only Boiler).
 - A. See Chart 2 for sensor data.
See Accessories section of this manual for wiring diagram.

| CHART 1 -1k Ω OUTDOOR AIR SENSOR DATA | | | |
|--|------------|-----------|------------|
| T [°F] | R [Ohm] | T [°F] | R [Ohm] |
| -4.0 | 7,578 | 53.6 | 1,690 |
| -2.2 | 7,193 | 55.4 | 1,621 |
| -0.4 | 6,831 | 57.2 | 1,555 |
| 1.4 | 6,489 | 59.0 | 1,492 |
| 3.2 | 6,166 | 60.8 | 1,433 |
| 5.0 | 5,861 | 62.6 | 1,375 |
| 6.8 | 5,574 | 64.4 | 1,321 |
| 8.6 | 5,303 | 66.2 | 1,268 |
| 10.4 | 5,046 | 68.0 | 1,218 |
| 12.2 | 4,804 | 69.8 | 1,170 |
| 14.0 | 4,574 | 71.6 | 1,125F |
| 15.8 | 4,358 | 73.4 | 1,081 |
| 17.6 | 4,152 | 75.2 | 1,040 |
| 19.4 | 3,958 | 77.0 | 1,000 |
| 21.2 | 3,774 | 78.8 | 962 |
| 23.0 | 3,600 | 80.6 | 926 |
| 24.8 | 3,435 | 82.4 | 892 |
| 26.6 | 3,279 | 84.2 | 858 |
| 28.4 | 3,131 | 86.0 | 827 |
| 30.2 | 2,990 | 87.8 | 796 |
| 32.0 | 2,857 | 89.6 | 767 |
| 33.8 | 2,730 | 91.4 | 740 |
| 35.6 | 2,610 | 93.2 | 713 |
| 37.4 | 2,496 | 95.0 | 687 |
| 39.2 | 2,387 | 96.8 | 663 |
| 41.0 | 2,284 | 98.6 | 640 |
| 42.8 | 2,186 | 100.4 | 617 |
| 44.6 | 2,093 | 102.2 | 595 |
| 46.4 | 2,004 | 100.4 | 617 |
| 48.2 | 1,920 | 102.2 | 595 |
| 50.0 | 1,840 | 104.0 | 575 |
| 51.8 | 1,763 | 106.0 | 556 |

| CHART 2 -10k Ω INDIRECT TANK SENSOR DATA | | | |
|---|------------|-----------|------------|
| T [°F] | R [Ohm] | T [°F] | R [Ohm] |
| 32.0 | 32,505 | 86.0 | 8,060 |
| 33.8 | 30,898 | 87.8 | 7,726 |
| 35.6 | 29,381 | 89.6 | 7,407 |
| 37.4 | 27,946 | 91.4 | 7,103 |
| 39.2 | 26,590 | 93.2 | 6,813 |
| 41.0 | 25,308 | 95.0 | 6,537 |
| 42.8 | 24,094 | 96.8 | 6,273 |
| 44.6 | 22,946 | 98.6 | 6,021 |
| 46.4 | 21,859 | 100.4 | 5,781 |
| 48.2 | 20,829 | 102.2 | 5,551 |
| 50.0 | 19,854 | 104.0 | 5,332 |
| 51.8 | 18,930 | 105.8 | 5,123 |
| 53.6 | 18,054 | 107.6 | 4,923 |
| 55.4 | 17,223 | 109.4 | 4,732 |
| 57.2 | 16,436 | 111.2 | 4,549 |
| 59.0 | 15,689 | 113.0 | 4,374 |
| 60.8 | 14,980 | 114.8 | 4,207 |
| 62.6 | 14,306 | 116.6 | 4,047 |
| 64.4 | 13,667 | 118.4 | 3,894 |
| 66.2 | 13,060 | 120.2 | 3,748 |
| 68.0 | 12,483 | 122.0 | 3,608 |
| 69.8 | 11,935 | 123.8 | 3,473 |
| 71.6 | 11,414 | 125F.6 | 3,345 |
| 73.4 | 10,919 | 127.4 | 3,222 |
| 75.2 | 10,447 | 129.2 | 3,104 |
| 77.0 | 9,999 | 131.0 | 2,991 |
| 78.8 | 9,572 | 132.8 | 2,882 |
| 80.6 | 9,166 | 134.6 | 2,778 |
| 82.4 | 8,779 | 136.4 | 2,679 |
| 84.2 | 8,411 | 138.2 | 2,583 |

Accessories:

1. 1k Ω Outdoor Temperature Sensor Kit - BD710487302V

Use Outdoor Sensor Kit with Heating Only or Combi Boilers. Wire Control to boiler M2 terminal strip terminals #4 and #5 as shown below.

Install/locate Control according to instructions supplied with sensor kit and Installation, Operation and Maintenance Manual (IOM).

Setting "Kt" Climate Curve:



Start boiler in CH mode. Depress CH control button once.



Boiler control will recognize installed OAS sensor. Display will change to show current default "Kt" value. Note display value.

When operation in CH mode, Kt value setting will override maximum CH boiler control set point based on current outdoor temperature.


- Refer to applicable °F (or °C) chart,
- Identify Kt range that will satisfy the desired boiler delivery temperature based on average (extreme) outdoor temperature range expected for climate location.



- Use lower value of range as the desired Kt value.
(Example): to deliver 186°F water @ OT of -20°F = Kt range is 90 thru 25. Select 25.
- To change "default" Kt value on boiler control use +/- CH Heating buttons.

When scrolling has stopped, boiler will automatically "SAVE" value as new Kt default value and automatically return to CH mode when no Kt adjustment activity is sensed. Kt values can be changed in +/- 1 point increments.

To return to check or change current Kt "default value - depress one of the CH set-point adjustment buttons (once), while in any heating or standby mode. Adjust Kt value to obtain desired comfort level.



Note For temperatures below -40°F (-40°C), maximum heating flow temperature set point no longer increases and curves on the graph become horizontal. Boiler set point will override sensor setpoint.

BUTTONS Key

| | |
|--|--|
| | DHW temperature adjustment (+ to increase the temperature and - to decrease it) |
| | Heating water temperature adjustment (+ to increase the temperature and - to decrease it) |
| | Boiler operating information |
| | Operating mode: DHW - DHW & Heating - Heating Only |
| | Off - Reset - Exit menu/functions |

Boiler Control Panel





2. 10k Ω Indirect Storage Tank Sensor Kit

Heating Only boiler can be electrically connected to Indirect Storage Tank.

Diagram of hydraulic connection of external indirect storage tank is shown below.

Connect DHW priority sensor to terminals #9 and #10 on terminal block M2. The element of the sensor must be inserted in the sensor well located on the indirect storage tank.

Verify the exchange capacity of the storage boiler coil is appropriate for power of the boiler. Adjust DHW temperature (+95°F...+140°F / +35°C...+60°C) by pressing   buttons on boiler control panel.



Note → Parameter PO3 for **Heating Only** boiler, with no indirect tank remains Factory Set at 08. No change is required.

If adding an Indirect Tank with a sensor to **Heating Only Boiler** - change PO3 parameter from 08 to 05.






If adding an Indirect Tank with a thermostat to **Heating Only Boiler** - change PO3 parameter from 08 to 04.

See Section 9, Parameter Settings, in boiler's Installation, Operation, and Maintenance Manual.

Parameter PO3 for **COMBI** boiler factory set at 00 requires no change.



BUTTONS Key

| | |
|---|--|
|  | DHW temperature adjustment (+ to increase the temperature and - to decrease it) |
|  | Heating water temperature adjustment (+ to increase the temperature and - to decrease it) |
|  | Boiler operating information |
|  | Operating mode: DHW - DHW & Heating - Heating Only |
|  | Off - Reset - Exit menu/functions |

Boiler Control Panel




125F FLOOR STANDING - HEAT ONLY WIRING DIAGRAM

MODEL 125F - Heat Only

240011359 REV C 125

- LEGENU - LEGENDE:**
- 1-FUSES 3, 15 A - Fusibles 3, 15 A
 - 2-Supply 120V - 60Hz - Alimentation
 - 3-Fan - Ventilator
 - 4-Air pressure switch - Pressostat différentiel fumées
 - 5-Safety Thermostat - Thermostat de Sécurité
 - 6-Gas Valve - Vanne a gaz
 - 7-Exchanger sensor - Sonde échangeur
 - 8-Water Pressure Switch - Pressostat Eau
 - 9-NTC return Sensor - Sonde NTC retour
 - 10-NTC flow sensor - Sonde NTC départ
 - 11-Flue Safety Thermostat - Thermostat Fumées
 - 12-Remote User Interface or Open Therm
 - 13-Prov. for Outside Sensor - Pred. Sonde Extérieure
 - 14-Link 24V - Joint 24V
 - 15-DHW Indirect sensor or T-Stat
 - 16-Flame Sensing Electrode - Electrode présence veilleuse
 - 17-Ignition Electrode - Electrode d'allumage
 - 18-Three Way Valve - Soupape Trois Voies
 - 19-Pump - Pompe
- M1-Main Power Terminal Board - Bornier d'alimentation
M2-Accessories Terminal Board - Bornier pour accessoires




* See wiring section of application guide for more details


WIRING DIAGRAM
 If any of the original wire as supplied with the appliance must be replaced, it must be replaced with wire having same specifications.
SCHEMA DE CABLAGE
 Si un câble d'origine, tel qu'il est fourni avec l'appareil, doit être changé, il doit être remplacé par un câble qui possède les mêmes caractéristiques.

- Bl = Blue - Bleu
- Br = Brown - Brun
- Bk = Black - Noir
- R = Red - Rouge
- GY = Green/Yellow - Vert/Jaune
- W = White - Blanc
- G = Green - Vert
- Gr = Grey - Gris
- IB = Light Blue - Celeste

150F FLOOR STANDING - COMBI WIRING DIAGRAM

MODEL 150F - Combi





'HEATING ONLY' BOILER (125,000 BTUH)

| | | BOILER OUTPUT (BTUH/HR) | | | |
|---------------------------------------|--------------|-------------------------|--------|--------|---------|
| | | 50,000 | 60,000 | 80,000 | 100,000 |
| H2O30 | | | | | |
| 1st HOUR RATING (GAL/HR) | 140 F | 94 | 106 | 106 | 106 |
| | 115 F | 119 | 138 | 158 | 158 |
| CONTINUOUS RATING (GAL/HR) | 140 F | 67 | 79 | 79 | 79 |
| | 115 F | 92 | 111 | 131 | 131 |
| H2O40 / H2O40L | | | | | |
| 1st HOUR RATING (GAL/HR) | 140 F | 103 | 115 | 119 | 119 |
| | 115 F | 128 | 147 | 174 | 174 |
| CONTINUOUS RATING (GAL/HR) | 140 F | 67 | 79 | 83 | 83 |
| | 115 F | 92 | 111 | 138 | 138 |
| H2O50 | | | | | |
| 1st HOUR RATING (GAL/HR) | 140 F | 112 | 124 | 133 | 133 |
| | 115 F | 137 | 156 | 192 | 192 |
| CONTINUOUS RATING (GAL/HR) | 140 F | 67 | 79 | 88 | 88 |
| | 115 F | 92 | 111 | 147 | 147 |
| H2O60 / H2O60L | | | | | |
| 1st HOUR RATING (GAL/HR) | 140 F | 121 | 133 | 147 | 147 |
| | 115 F | 146 | 165 | 208 | 208 |
| CONTINUOUS RATING (GAL/HR) | 140 F | 67 | 79 | 93 | 93 |
| | 115 F | 92 | 111 | 154 | 154 |

Notes:

**176 °F Boiler Supply Water Temperature
 AHRI Rating Conditions - 50 °F Inlet Water
 @ 4.0 GPM FLOW RATE**

Boiler output over 100,000 BTU does not effect tank performance.

A - LOW WATER CUTOFF

Low Water Cut Off - Heating Only and Combi Boilers

These guidelines are supplied when necessary to install an additional Low Water Cut Off (LWCO), for sensing a low water level condition in a boiler, as required by the Authority Having Jurisdiction.


Follow LWCO manufacturer installation instructions for type of LWCO selected in addition to these instructions.

LWCO shall be 120V/60HZ control and dry contacts sized for load being connected. Wire control to boiler. See Figure 1.

Connect LWCO device to the system ground. Ground in accordance with the requirements of the authority having jurisdiction or, in the absence of such requirements, with the National Electrical Code (NEC) or Canadian Electrical Code CEC.

- Locate LWCO sensing device in the supply piping, above the minimum height of boiler. See Figure A-2, Piping Diagram.
- Position control in HORIZONTAL piping to assure proper boiler protection (upright or 90° rotation).
- For proper operation, sensing element of the LWCO control shall be positioned in the tee to sense the main water stream. Maintain minimum 1/4" spacing from pipe walls. Element shall NOT contact the rear, or side walls of the tee. See Figure A-3.
- Install an air vent using a tee to avoid nuisance shutdowns.
- Apply small amount of pipe sealant to threaded connections.
- Arrange piping to prevent water dripping onto boiler.
- DO NOT install water shutoff valve between boiler and LWCO sensing device.

LWCO Wiring Diagram




LOW WATER CUTOFF


Piping Diagram - LWCO Location

Note Arrange piping to prevent water dripping onto boiler.




Note Illustrations are meant to show system piping concept only. Installer is responsible for all equipment and detailing required by authority having jurisdiction.



* Check Local Codes for Maximum Distance to Floor.

Note  DO NOT PLACE ISOLATION VALVE BEFORE TEE OR LWCO.

Low Water Cutoff - Detail



ERROR CODE TABLE

NOTE: When instructed press and hold the 'Reset' for between 1-3 seconds to reset the boiler.

Table Of Error Codes

| | |
|---------|---|
| E 09 | Gas valve connection cable |
| E 10 | External probe fault |
| E 12 | Water flow switch open |
| E 13 | Water flow switch close |
| E 15 | gas valve fault |
| E 18 | Water refill enabled |
| E 19 | Max time of water refill |
| E 20 | Central Heating Flow NTC Fault |
| E 28 | Flue NTC Fault |
| E 40 | Central Heating Return NTC Fault |
| E 50 | Hot Water NTC Fault (tank version) |
| E 53 | Obstruction on the flue pipe- combustion off |
| E 55 | PCB to be set by the "Calibration Function" |
| E 71 | Fan parameter Out of range in autocalibration |
| E 72 | Combustion test Out of range in autocalibration |
| E 77 | Current out of range |
| E 78 | Minimum gas valve current |
| E 79 | Maximum gas valve current |
| E 83-87 | Communication error |
| E 92 | Combustion test alarm during auto-setting |
| E 109 | Pre-Circulation Fault |
| E 110 | Safety Thermostat Operated |
| E 117 | System Water Pressure Too High |
| E 118 | System Water Pressure Too Low |
| E 125 | Circulation Fault (Primary Circuit) |
| E 128 | Flame Failure |
| E 129 | Frequently loss of flame during the ignition |
| E 130 | Flue NTC Operated |
| E 133 | Interruption Of Gas Supply or Flame Failure |
| E 134 | Elapsed time Gas valve open without gas |
| E 135 | Interruption Of Gas Supply (internal error) |
| E 160 | Fan or Fan Wiring Fault |
| E 321 | Domestic Hot Water NTC sensor fault |
| E 384 | False flame |
| E 385 | Under voltage |

Initial Fault Finding Checks

1. Check that gas, water and electrical supplies are available at the boiler.
2. Electrical supply = 120V ~60 Hz.
3. The preferred minimum gas pressure is 3.5"wc for Natural gas and 10"wc for LPG.
4. Carry out electrical system checks, i.e. Ground Continuity, Resistance to Ground, Short Circuit and Polarity with a suitable meter.

NOTE: These checks must be repeated after any servicing or fault finding.

5. Ensure all external controls are calling for heat and check all external and internal fuses. Before any servicing or replacement of parts, ensure the gas and electrical supplies are isolated.

1. If a fault occurs on the boiler an error code may be shown by the facia display.

E 20, E 28, E 40, E 50, E 160, E 321 and E 431 indicate possible faulty components.

E 53 shows possible obstruction in the flue duct.

E 55 indicates that the pcb is not setting/calibrated.

E 71, E 72, E 77, E 78 e E 92 indicate possible wrong calibration. A new calibration is needed.

E 92 shows possible flue recirculation in the flue duct.

E 83...87 shows possible error of communication with thermostat (Goto section P)

E 110 shows overheat of the primary.

E 117 is displayed when the primary water pressure is more than 43 psi.

E 118 is displayed when the primary water pressure is less than 7.25psi.

E 125 is displayed in either of two situations:-
 i) If within a time between 15..30 seconds of the burner lighting the boiler temperature has not changed by 2°F.
 ii) If within 10 minutes of the burner lighting the boiler temperature twice exceeds the selected temperature by 80°F. In these instances poor primary circulation is indicated.

E 128 is displayed if there has been a flame failure during normal burner operation.


E 133 , E 134 and E 135 indicate that the gas supply has been interrupted, ignition has failed or the flame has not been detected.

2. By pressing the 'Reset' button for between 1-3 seconds when E 110, E 125, E 133, E 134, E 135 , E 09, E 15, E 128 and E 384 are displayed it is possible to relight the boiler.

3. If this does not have any effect, or error codes are displayed regularly further investigation is required.

TROUBLESHOOTING CHART


Central Heating






* If 09, 15 and 384 is flashing or re-occurs regularly check all PCB connections, if this has no effect replace the PCB.

TROUBLESHOOTING CHART

Domestic hot water




Fault Finding Solutions Sections




FAULT SOLUTION SECTIONS


D




E



F




G




FAULT SOLUTION SECTIONS


H




I



J




K




FAULT SOLUTION SECTIONS

L




M




N

Performs the autocalibration function (see the Service manual)



O



P

Check the electrical connection between Ru and pcb



ECR International Inc. 2201 Dwyer Avenue, Utica, NY 13501
Tel. 800 253 7900
www.ecrinternational.com

All specifications subject to change without notice.
©2019 ECR International, Inc.

IMPORTANT INFORMATION
READ THIS LEAFLET BEFORE COMMISSIONING THE BOILER

IMPORTANT:

**Upon startup of this new boiler please call
ECR International, Inc. Technical Support
for installation assistance and registration.**

**Technical Support and Product Registration
Monday - Friday 8AM to 6PM Eastern time.
1.800.253.7900**

Described below is the procedure to activate the De-Aeration Function/Gas Type Check when power is first supplied to the boiler and the actions required when on a Gas E (LPG) supply.

De-Aeration Function

- When power is supplied to the boiler for the first time **000** will be displayed. If **⏻** is shown, press **⏻R**, for at least 2 seconds **000** will now be displayed.
- Press **iP** & **||||+** together and hold for at least 6 seconds. The “De-Aeration” Function will be activated & “On” showing.
- The boiler pump will run for up to 10 minutes. For 3-way valve models the valve will switch between heating & hot water. This will purge air from the system. The display will show **3 12**.

Gas Type Check

- Once de-aeration is complete on first fire-up the boiler will light and operates for 6 or 7 minutes to automatically check the gas type Gas A (Natural Gas “NG”) or Gas E (Liquefied Petroleum Gas “LPG”). The boiler software check the combustion value against the set value. **000** will be displayed alternating the % value of ignition power and the temperature value °F(°C).
- On a Gas A (Natural Gas) supply the display shows **n G** for at least 10 seconds and the boiler is ready for the normal operation. If the display shows **LPG**, press **⏻R** & **iP** together and hold for at least 4 seconds to exit the function without saving.
- On a Gas E (LPG) supply the display show **LPG**, press **iP** for at least 6 seconds to confirm that this is the intended gas type for the installation.
If the display shows **n G**, press **⏻R** & **iP** together and hold for at least 4 seconds to exit the function without saving then modify **P02=01** as described in the Manual Instructions for the Installer section “PARAMETERS SETTING”.
- While the gas type is being identified, the boiler may be noisy.

IF THE BOILER IS TO BE OPERATED ON GAS E (LP) REPLACE THE EXISTING LABEL WITH THE GAS E LABEL SUPPLIED WITH THIS INSTRUCTION. ASSURE FACTORY SUPPLIED CONVERSION LABEL IS APPLIED TO PRODUCT IF CONVERTING TO LP.

IMPORTANT: Gas type Check

Ensure the maximum heat exchange to the system in Heating or DHW mode (DHW request) in order to avoid the boiler shutoff for overheating.



FUNCTION INTERRUPT

If either De-aeration or Gas Check is interrupted by electrical power failure is necessary to reactivate the function by pressing **iP** & **||||+** together for at least 6 seconds. During De-aeration, if the display shows E118 (water low pressure), open the water filling tap and repressurising the system to the correct pressure value. During Gas Type Check, if the display shows E133 (Ignition Failure), press **⏻R** button to Reset then press together **iP** & **||||+** for at least 6 seconds to restart the function. During Gas Type Check, if the boiler switch off for overheating failure is necessary to reactivate the function by pressing **iP** & **||||+** together for at least 6 seconds.

IMPORTANT: The combustion for this appliance has been checked, adjusted and pre-set at the factory for operation on the gas type specified on the appliance data plate.

During the Gas Type Check Function the combustion ratio will increase for a short time while the gas type is established.

The display shows the Gas Type Check



CG_2120

INFORMATIONS IMPORTANTES



LIRE CET IMPRIMÉ AVANT DE METTRE LA CHAUDIÈRE EN MARCHÉ

IMPORTANT : Lors du démarrage de cette nouvelle chaudière veuillez appeler recueil International, Inc. de support technique pour l'assistance à l'installation et l'enregistrement.



Support technique et enregistrement du produit
lundi - vendredi 8h00 à 18h00 heure de l'Est.
1.800.253.7900

Ci-après la procédure d'activation de la Fonction Désaération/Identification Type de Gaz lorsque la chaudière est raccordée pour la première fois à la réseau électrique et les actions à mettre en œuvre en cas d'alimentation avec du gaz propane.

Fonction Désaération

- Lorsque la chaudière est raccordée pour la première fois à la réseau électrique l'afficheur indique **000**. Si  est affiché, appuyer pendant au moins 2 secondes sur la touche  ; l'afficheur montrera alors le symbole **000**.
- Appuyer simultanément sur les touches **iP** et **|||+** pendant au moins 6 secondes. La fonction « Désaération » est alors activée et l'indication « On » apparaît sur l'afficheur.
- La pompe de la chaudière se met en marche pendant environ 10 minutes. Pour les modèles à production instantanée d'eau chaude, la vanne à 3 voies effectuera la commutation entre les fonctions chauffage et eau chaude sanitaire, ainsi que la purge de l'air présent dans l'installation. L'afficheur indique **3 12**.

Identification du type de gaz

- Quand la désaération est terminée la chaudière se mise en marche pendant environ 6-7 minutes pour vérifier automatiquement le type de gaz utilisé **nG** Gaz A (gaz naturel) ou Gaz E **LPG** (gaz liquide). Le logiciel de la chaudière compare la valeur de combustion avec la valeur prédéfinie. L'afficheur montre **000**, en alternance avec la valeur en % de la puissance d'allumage et la valeur de la température °F (°C) de départ du chauffage.
- Si la chaudière est alimentée au Gaz A (gaz naturel), l'afficheur indiquera **n G** pendant environ 10 secondes. La chaudière est donc prête à fonctionner normalement. Si l'afficheur montre **LPG** appuyer simultanément sur les touches  et **iP** pendant au moins 4 secondes pour quitter sans modifier le réglage d'usine.
- Si la chaudière est alimentée au Gaz E **LPG** (gaz liquide), l'afficheur montrera **LPG**. Appuyer pendant au moins 6 secondes sur la touche **iP** pour valider le type de gaz effectivement utilisé. Si l'afficheur indique **n G** car le gaz d'alimentation n'est pas reconnu, appuyer simultanément sur les touches  et **iP** pendant au moins 4 secondes pour quitter la fonction, puis modifier le paramètre **P02=01** comme cela est décrit dans le manuel d'utilisation pour l'installateur dans « CONFIGURATION PARAMÈTRES » de la chaudière.
- Pendant le phase d'identification du type de gaz la chaudière peut être bruyante.

Si la chaudière est exploitée à GAS E (LP) remplacer l'étiquette existante avec le gaz E ÉTIQUETTE FOURNIE AVEC CETTE NOTICE. Assurer la conversion de la configuration usine étiquette est appliquée au produit SI LA CONVERSION DE LP.


IMPORTANT : Identification du type de gaz

Garantir l'échange thermique maximum à l'installation de chauffage ou de production d'ECS afin d'éviter que la chaudière ne s'éteigne suite à un problème de surchauffe.

INTERRUPTION DE LA FONCTION

Si la fonction de désaération ou d'identification du gaz est interrompue par une coupure de l'alimentation électrique, une fois que le courant est rétabli, réactiver la fonction en appuyant simultanément sur les touches **iP** et **|||+** pendant au moins 6 secondes.

Si pendant la Fonction de Désaération l'afficheur signale l'erreur E118 (basse pression du circuit hydraulique), manœuvrer le robinet de remplissage de l'appareil pour rétablir la pression correcte.



Si la fonction d'identification du gaz est interrompue suite à une erreur (par exemple, E133 absence de gaz), appuyer sur la touche  pour réinitialiser, puis appuyer simultanément sur les touches **iP** et **|||+** (pendant au moins 6 secondes) pour réactiver la fonction.

Si la fonction d'identification du gaz est interrompue suite à un problème de surchauffe, réactiver la fonction en appuyant simultanément sur les touches **iP** et **|||+** pendant au moins 6 secondes.

REMARQUE : la combustion de cet appareil a été contrôlée, étalonnée et prédéfinie en usine pour fonctionner avec du gaz NATUREL.

Pendant la Fonction de Contrôle du Type de Gaz, le rapport de combustion augmentera pour une courte durée afin de permettre l'identification du type de gaz.

L'afficheur montre l'identification du type de gaz.



CG_2120

Required Inspection Schedule To Be Completed By Qualified Service Technician

| Inspection Items | | | Date Completed | | | |
|---|---------------------------|---|----------------|--------|--------|---------|
| | | | Year 1 | Year 2 | Year 3 | Year *4 |
| Piping | Near boiler piping | Check boiler and system piping for any sign of leakage, verify pipes are properly supported. | | | | |
| | Vent | Check condition of all vent pipes and joints. Verify vent piping terminations are free of obstructions and blockages. | | | | |
| | Safety Relief Valve | Follow safety relief valve manufacturer's instructions for maintenance and repair. Verify discharge pipe properly installed per IOM. | | | | |
| System | Visual | Do full visual inspection of ALL system components. | | | | |
| | Functional | Test all functions of the system (heat and safety) | | | | |
| | Temperatures | Verify safe settings on boiler or anti-scald valve. | | | | |
| Verify programmed temperature settings. | | | | | | |
| Electrical | Connections | Check wire connection. Verify connections are tight. | | | | |
| | Smoke and Co detector | Verify devices are installed and working properly. Change batteries if necessary. | | | | |
| | Circuit Breakers | Check that circuit breaker is clearly labeled and operates correctly. | | | | |
| Chamber/ Burner | Combustion Chamber | Check burner and combustion chamber. Clean following directions in maintenance section of IOM. Replace gaskets whenever checking combustion chamber. | | | | |
| | Spark Electrode | Clean. Set gap according to IOM directions. Clean electrode with plumbers cloth to remove oxides. | | | | |
| | Flame Sensor | Clean sensor. | | | | |
| Condensate | Neutralizer | Check condensate neutralizer - replace if necessary. | | | | |
| | Condensate pipe/trap | Disconnect condensate pipe. Clean out any dirt or accumulation. Fill with water level of outlet and reinstall. NOTE: verify flow of condensate, make sure hose is properly connected during final inspection. | | | | |
| Gas | Pressure | Measure incoming gas pressure per IOM. | | | | |
| | Pressure drop | Measure drop in pressure on light off verify with IOM. | | | | |
| | Leaks | Check gas piping. Test for leaks and signs of aging. Make sure all pipes are properly supported. | | | | |
| Combustion | CO/CO ₂ Levels | Check CO and CO ₂ level in exhaust. See Start-up Procedures for ranges. Record at high and low fire. | | | | |
| Safety | All Sensors | Check continuity of all sensors. Replace if corroded. Verify all connections through ohms reading. | | | | |
| Final Inspection | Check List | Verify you have completed entire check list. | | | | |
| | Homeowner | Review findings and service with Homeowner. | | | | |

* Continue inspections beyond 4th year. Maintenance should continue annually for the life of the boiler to ensure safe worry free operation.